

card. Type in your message and click “send”.

3. To reply or forward a message, select and click on “Reply/Forward”.

You don’t need your mobile handy whenever you want to send a message because the router has its own contact manager which can be used to add, edit or delete contacts.

- ▶ To add a contact, click the Contacts button. Now, select “Add” and enter the contact name and the phone number. Click “OK” and the contact will be saved on your SIM card.



Start messaging



New message dialog box

- ▶ To edit a contact, click the Contacts button and select “Edit”. Make the necessary changes and click “OK” to save your changes.
- ▶ To delete a contact, select the contact and click on the delete button. To delete all contacts, click “Select All” and hit the Delete button.

If you already have your contacts in vCards, you can import them here in just a few clicks. Go to Contacts and click the Import button. Select the vCards you want to import and click Open. After the import, a message will display the important contact information. You can also export your existing contacts by clicking the Export button and selecting the destination to save the vCards. Click “OK” to export the cards. A message will be displayed after the transfer is complete. 