

That's because your phone will treat this account as the account you want to use with Zune and Xbox Live.

If you've used either of these services before, it's important to sign in with your phone to the same Windows Live ID you've used previously for Zune and Xbox. Otherwise you won't get the same functionality out of the Zune and Xbox areas of your phone. Your phone will warn you about this when you add a Windows Live account; however, if you're unsure what Windows Live account you used for Zune or Xbox previously, you should find this information out before adding any accounts. This will enable you to make sure you add the correct account first. To find out what Windows Live ID your Xbox Gamertag is associated with, fire up your Xbox and sign in. Next, go to Settings . Account Management . Windows Live ID to get the account name. To find out what Live ID account your Zune Tag is associated with, open the Zune software on your computer and sign in. Next, right-click your profile picture and choose Switch User. The email address listed next to your profile picture on the Sign In screen is your Windows

Once you know the Windows Live ID you'd like to use, you're ready to add the account to your phone. (Of course, if you already signed into a Windows Live ID during the initial setup process described, you can skip these steps unless you have additional Windows Live IDs or Hotmail accounts you would like to add!) Follow these steps to add a Windows Live account to your phone:

1. Turn on and unlock your phone.
2. Tap the arrow in the upper right of the screen to bring up the applications list. At the bottom of the list, tap Settings.
3. Accessing account settings on your Windows Phone 7.
4. Tap email & accounts. 4. Tap add an account .
5. Tap Windows Live to add a Windows Live or Hotmail account.
6. If this is the first Windows Live account you're adding, you'll see a screen explaining how your first Windows Live ID will be associated with Zune and Xbox. Tap next to continue.
7. Enter your Windows Live username (including the part after the @ symbol) and password in the boxes provided, and then press sign in. Assuming you entered your information correctly, the account will be added.
8. If you have more than one Windows Live account to add, press the start button on your device and repeat Steps 2 through 7 until you've added all of your desired Windows Live accounts to your phone.