

most recently been added to the device. This can include music, videos, podcasts, or any other content types supported by Music + Video.

From a presentation standpoint, the Zune section is displayed as a plain text list, but the other two default sections, History and New, utilise graphical thumbnails representing individual artists and albums.

Watch videos

The Zune Videos interface provides a simple front end to the video content you've synced from the PC and access to the even simpler Windows Phone media player. The interface

is divided along the same pivots as is the Zune PC software's Videos collection, with separate sections for All, TV, Music (music videos), Movies, Other, and Personal. There aren't a lot of options here. You can scroll through the lists to find the video you want. If you tap the video, it will begin playing, full screen or nearly so. And you can tap and hold on individual items to pin them to the Start screen or delete them from the device.



The Now Playing screen

Listen to the radio

The Zune Radio experience is pretty straight forward but comes with a few interesting twists. When you select Radio from the Zune section, you're presented with the simple radio interface shown on screen.

This interface has just a few elements to consider. In the center of the screen is the virtual radio dial. To scan for in-range stations, just flick left or right in the center of the screen and the radio will seek the next available station. When it finds one, it will stop. When you're tuned into a station, you will see information about the station name and, if the station provides RDS or RT+ signals, the currently playing song and artist name. You can press the Add button (which looks like a "+" sign and a star) in the top left of the screen to add the current station to your list of favourites. Additionally, a Pause button appears in the lower center of the screen; press this button to pause FM radio playback. Tap it again to resume playback. There's also a Favorites button in the lower left of the screen. Tap this to bring up the list of saved favorite stations.