

Wi-Fi media sync



Marketplace on the
Windows Phone device

While you must initially sync media between your Windows Phone and the PC via a USB cable, you can perform subsequent syncing, automatically, and wirelessly, via your home's Wi-Fi network. So anytime your phone connects to your home Wi-Fi network in the future, it will automatically and wirelessly stay up to date with the latest music, videos, podcasts, and other content that you wish to sync. To configure this feature, connect your phone to the PC and sync normally. Then, in the Zune PC software, choose Settings, Phone, and then Wireless Sync. Then, just step through a short wizard that determines which Wi-Fi network will be used for automatic Wi-Fi media sync. It's that simple.

Zune promiscuity

One of the best things about the Zune PC software is that it doesn't lock you into connecting your device to just a single PC, as does Apple's rigid iTunes software. You will typically configure a single PC to be linked with your Windows Phone for media sync purposes. But if you have multiple PCs, you can connect your Windows Phone to those PCs, as a guest, and copy content back and forth. You can use your Windows Phone as a conduit between two or more PCs, copying content back and forth between all of them, as long as you've logged on with your Windows Live ID on each. 