

switch. In the On position, the phone's cellular (voice and data), Wi-Fi and Bluetooth radios function normally and can be configured via their individual Settings interfaces (cellular, Wi-Fi, and Bluetooth, respectively). So when Airplane Mode is disabled, you're free to enable or disable the other features independently. When Airplane Mode is set to Off, all three of the radio types are shut down in unison. When the phone is in Airplane Mode, a tiny icon signifying the same appears in the status bar.

Configure accounts

You obviously know by now that you log on to your primary Windows Live account as part of the initial experience. But most people have other accounts, too. These include accounts associated with email, calendars, contacts and other services, and they come from a variety of sources online.

Windows Phone supports multiple account types, including explicit account types such as Windows Live, Outlook (Exchange), Facebook and Yahoo! as well as other account types implicitly through more advanced and complicated configuration interfaces. And it supports multiple instances of account types too, so you could configure, say, two different Google accounts if you wanted. Further complicating matters, the available services in each account differ from account type to account type. So with all of that in mind, here are the different account types offered in Windows Phone.

- ▶ **Windows Live:** As discussed previously, everyone who uses Windows Phone will need a Windows Live ID. This is the key to having a great experience, but is also required for certain phone features. So it's a primary account and behaves differently than other accounts. When you configure your primary Windows Live account on the phone initially, it connects to your contacts list, photos and feeds, automatically and behind the scenes. These features can't be individually configured. You can, however, later enable email sync on your primary Windows Live account if you'd like, from within the phone's Settings interface. And if you navigate to the Calendar app, you'll see that Windows Live calendar sync is enabled automatically. But you can turn off calendar sync from there if you didn't want that. One thing you can't do is disable contacts sync on your primary Windows Live account. It's on, and there's no way to change that. Of course, Windows Phone supports multiple Windows Live accounts, though the secondary accounts only offer email, contacts