

- ▶ First, replace your “recovery manager” with ClockworkMod Recovery.
- ▶ Then perform the process of flashing your firmware, selecting the ROM you’d like to flash it with (in this case, CyanogenMod).
- ▶ You have to download it, and will be informed to back up data since your device will be doing a factory restart.
- ▶ Back up your data and stock firmware using ClockworkMod Recovery before activating CyanogenMod.

You can also copy CyanogenMod and the required app files to an SD card’s root, which can then be installed using ClockworkMod Recovery.

There are many other custom ROMs, some of which maybe requiring root access. Always remember to go for the ROM that would best suit your needs. Read up on the different ROMs and freshen up on the flashing and installation process before trying any custom ROMs. Talking about reading up, you can just read on - you can find all the comprehensive coverage you need in this FastTrack itself!

How about hacking non-communication devices?

Behold, ye mortals! If we say we will give you a comprehensive coverage of device hacking, we will give you a comprehensive coverage of device hacking. That includes non-communicative devices like PMPs and even digital cameras? So be it.

Devices like these have only started receiving powerful hardware components recently, and it is for this reason that the interest in hacking these was a little late to develop. Still, now that it’s there, it is getting its due recognition. The hacks here are mostly performance enhancing ones, like maybe better media rendering for the PMPs, or producing RAW images for low and mid-range cameras. Not that it is limited to these upgrades, but these are the main motivations. More on this later. 