

ROFS1, ROFS2, ROFS3. By default, they will be assigned value '2B'. You need to change them to '2C'. Press ok.

12. Next you need to do is press 'Extend ROFS'. You'll see that the size will increase to around 163MB.
13. Now press 'Save Firmware'. This will take time too. Do not worry.
14. You'll see a file named 'RM-774_112.010.1404_79u_prd.core_BACKUP_.fpsx' will be created at the location of your firmware files.
15. Download and install Phoenix



Select your variant

16. Before using phoenix, create a folder in C:\Program Files\Nokia\Phoenix\Products and name it according to your RM version. For example, RM-774 as in our case. Phoenix will look up here while flashing.
17. Copy all the firmware files you downloaded from Navifirm, here. Do not copy the '.core_BACKUP_.fpsx' file. Also, do not cut-paste the original firmware files. If something goes wrong, you need to use your original firmware files to get your phone back.
18. Now, for CFW, you will need modified core,uda,rofs2 and rofs3 files. Head over to <http://dgigit.in/NDcOaP> (or you can google them) to get a list of CFWs. Select the one which suits your need according to your phone model. Different developers add different mods and pack their FW.
19. They will either provide all the FW files, or the four above mentioned files. If they have provided all the firmware files, download and extract them in RM-XX folder which you created. Replace the files which you pasted earlier.
20. If they provide only those four files, copy them to RM-XX folder and replace it with your original firmware files.
21. Now your firmware is ready to be flashed with Phoenix.
22. Open Phoenix- Open product- Scroll down to your RM version and select it. No screen will open. That's ok
23. Now select Flashing-Firmware Update- press '...' as shown in the screenshot
24. Scroll down to your product code and press ok.