

Micro-SIM. However, punching the same to get a Nano-SIM is not advised as the shearing can cause damage to the SIM card. Also, the thickness of a Nano-SIM is 15% lesser compared to its predecessors so it's best to contact your service provider and get a new SIM. There are adapters available to use your Micro-SIM in a Mini-SIM phone, or you could save the punched plastic as an adapter as well.

Radio+RDS

Radio is something that has survived quite a lot and still exists in most mobile phones and tablets. Since the technology has remained unchanged for decades there isn't much new however, phones do come with RDS these days. RDS stands for Radio Data System, it is a protocol by means of which the radio station can embed bits of information along with the regular transmission.

There are predefined fields which can be transmitted, each field pertains to a certain context. All of this is text based communication. Common fields include:

AF (alternative frequencies)

If the current FM signal becomes too weak then the receiver can obtain an alternate channel by reading this field and switch to that to get better reception.

CT (clock time)

This field gives the current time as transmitted by the radio station.

EON (enhanced other networks)

This allows the receiver to check other stations mainly for traffic updates.

PI (programme identification)

This field identifies a particular station with the country of origin.

PS (programme service)

On most occasions the only way to identify a Radio station is by identifying the radio jockey or wait for the station's unique chime. With the PS field the station can transmit 8 characters to identify itself.

PTY (programme type)

There are 31 predefined program types, using this field the station can