

Swiping down

To complete this action, you need to place your finger above the top of the screen, and swipe down towards the middle of the screen. If you are inside a running app, this will bring down the app settings panel (if applicable to the app in question). If you're in the BlackBerry Hub, the screen that lists running apps or the home screen, this brings down the quick settings menu where you can turn on or off Bluetooth, Wi-Fi, Alarm and Notification settings, and also access the phone settings.



Swiping to scroll

Like with any touchscreen device, swiping across the screen scrolls vertically or horizontally, depending on the direction of your scroll. When swiping up or down, if you started your action inside the screen area, you will scroll, if you started from the bezel, you will perform a gesture. Swiping left and right works exactly as it should; the only difference is that when you're not inside an app, and are in the BlackBerry Hub, the running apps screen or the home screen (where installed apps are displayed), swiping left and right will cycle you through these screens.



Two finger swipe up

This is only applicable to devices without hardware keyboards that are running the BlackBerry 10 OS. If you want to show the on-screen keyboard at any time, all you need to do is swipe up from the bezel using two fingers. Swiping down with two fingers minimises the keyboard again.



Other actions

Tap

Like with any other touchscreen device you've ever used, tapping on an item launches / opens it, or if it's an item that cannot be opened, selects it.