

top of the other app / icon you want to group it with. The OS will automatically group them together in a new folder, and offer up a suggested name that you can change right at the start. To add more icons / apps to this new folder, repeat the action, but this time, drop the icon you're moving on to the folder.

Lock / unlock

To lock the screen when active, or to unlock the screen, just press the power button on the top once.

Restart

Hold down the power button for a bit till you see a new black screen. Tap on the Restart icon to restart. If you get here by mistake, just press and release the power button to go back, or tap on the Cancel icon.

Power down

To turn off the phone, press and hold the power button, and you will see a 3 second countdown. If you hold the power button down until this countdown completes, the phone will power off.

Select multiple

Hold down your finger on any list item (email, pictures, songs, etc) and when the context menu pops up, tap on Select More. Now just scroll and tap on as many items on the list as you want to select. Once done, you can perform whatever actions are available in the context menu – delete, share, mark as read, etc., depending on what list you're viewing of course.



Selecting multiple things

Show the menu

Often, when you're scrolling down (swiping up) through long lists (such as emails), you will find that the menu that's normally at the bottom of the screen disappears. This is a feature to give you more screen real estate when scrolling (and less distracting icons and menus). If you want to bring back the bottom menu band, just stop scrolling down, and swipe your finger ever so slightly downwards to bring back the menu.