


the dropdown. You can then quickly change permissions

Device Password

Here you can set a password for your phone, and also set the time period of inactivity after which the device locks. You should enable the Allow Apps to Extend Password Lock Time, so that the device doesn't lock while, say, you're watching a video or a YouTube video in your browser.

SIM Card

Here you can add your phone number, if it's not already added from your service provider. You can PIN lock your SIM with SIM PIN 1 and SIM PIN 2 codes. No one really uses this anymore, but in case you do, now you know how to do it. The Phone Network Lock status tells you whether your phone or SIM is locked to the network or not.



Application permissions

Encryption

For added security of your personal data, you can encrypt your device and media card. This will ensure that if you ever lose your phone, and someone takes out the media card, they will not be able to access any of the data stored on it without knowing the correct password and having your specific device (which needs to be unlocked with your password, again). Remember, however, that if you wipe your phone without turning the encryption off for the media card, then all data on it might become unusable.

Parental Controls

If this is a phone for your child, you can turn on Parental Controls. When you do, you will be asked to set a password, and then you can choose to only let contacts saved in the phone call or text your child. You can also choose whether you want your child to have access to various features. The options available are: Camera and Video Features, Browser, Twitter,