

your LED flash into a flashlight for those dark scary rooms. The Timer option sends you to the Clock app and opens the timer setting. The Calculator app opens up with the next option in case you need to add or multiply something really fast. The Camera app opens with the last option and you're set to click away.

The Control Centre converges the most often used features and settings in one place making it a lifesaving and time saving option for the smartphone.

Parallax View

Relax. This has nothing to do Green Lantern or worse - Ryan Reynolds. The Parallax view option is a cool but inevitably unimportant component of the iOS 7 user interface. The OS uses the various sensors in the phone to project a pseudo-3D image in wallpapers and interface animations. Some people may find the view a bit uncomfortable to their eyes and stomachs. It's easy enough to switch off with a quick jump to Settings - General - Accessibility and turn off the Motion options.

Making Calls

It's called a phone for a reason. The iPhone's iOS comes with a host of new and revamped features but the fundamentals remain pretty much the same.

Phone App

The phone app on the iPhone rests in the bottom left corner. A touch pops it up to your screen and presents you with the Recent calls list by default. The top of the screen presents two adjacent tabs in the centre - "all" and "missed". Switching between these gives you a list of all calls made and received, or just the missed calls respectively. To the right of these options is the "Edit" option which once touched changes the appearance of the list. Firstly, to the top left appears "Clear" that if touched can be used to clear all recent contacts. Don't worry, it double checks with you before actually clearing the list. The second change is the appearance of red stop signs to the left of every call made. Touching these icons will allow you to selectively and individually delete calls made from the complete list. All deletions occur through confirmation so you're saved from touchscreen accidents. At any time you can touch "Done" on the top right and revert to the normal phone app screen.

At the bottom of the phone app screen are five icons, from left to right they are: Favourites, Recent, Contacts, Keypad and Voicemail. Touching any of