



AI protecting Biodiversity in Hawai

Artificial Intelligence is helping in protecting biodiversity in Hawai.

<https://digit.in/may22-64>



Niantic making an AR pet game

Pokemon Go developers Niantic are making an AR pet game called Peridot.

<https://digit.in/may22-65>

ging. This needs to be switched on. Debugging options provide ways to configure on-device debugging, and to establish communication between the device and your computer from which you will be trying to install the custom recovery on your phone.

Unlock Bootloader

The steps to unlock your bootloader vary a little from manufacturer to manufacturer. Please check for the exact steps for your phone. The steps mentioned below are generic for Android.

Log in or create an account at your manufacturer's bootloader unlocking page, choose your device (if requested), and log in or establish an account. The rest of this step varies depending on your phone, but the manufacturer's website should be able to guide you through it. This is what it will sound like: To begin, switch your phone off and enter fastboot mode. This varies by phone, but on most recent handsets, holding the "Power" and "Volume Down" keys for 10 seconds will get you there. You should now be in fastboot mode after releasing them. (HTC users must first select "Fastboot" using the Volume Down key and then click the power button.) You can generally get more information on your individual phone by conducting a fast Google

search, so do that now before proceeding.

Use a USB cord to connect your phone to your computer. The gadget should show up as linked on your phone. Open the platform-tools folder in your Android SDK folder on your PC and Shift+Right Click on an empty spot. Choose "Open a Command Prompt Here" and enter your unlock key in the Command Prompt box as instructed by your manufacturer. (For example, Motorola phones use the `fastboot oem get unlock data` command, whereas HTC phones use the `fastboot oem get identifier token` command.)

Enter the command to unlock your device:

`fastboot oem unlock`

Your phone may ask whether you're sure you want to unlock once you've done the command. To confirm, use the volume keys.

When you're done, reboot your phone using the on-screen menu (or run the `fastboot reboot` command from your PC). If everything went well, you should get a new message at boot stating that your bootloader has been unlocked, and it should boot into Android after a few seconds. Before



doing anything else, like flashing a custom recovery, make sure you boot into Android.

You've successfully unlocked your phone! You won't notice much of a change right now,

but an unlocked bootloader will allow you to flash a custom recovery, giving you root access and allowing you to install custom ROMs.

Install TWRP

This will differ depending on your operating system, but you'll need to open a command prompt in the location where your Android SDK tools were installed/extracted. In this folder, you'll also need to put your TWRP image file.

To get a list of connected Android devices, type the following in the command window:

`adb devices`

To reboot your device into bootloader/fastboot mode, use the following command:

`adb reboot bootloader`

After that, run:

`fastboot flash recovery`

`twrp-3.6.X-XXX.img`

Make sure to replace the TWRP version in this line of code with the one that matches to the one you want to install on your device.

Finally, execute the following code:

`fastboot reboot`

After you've accomplished that step, you'll be able to use the TWRP custom recovery to boot up your device and use its features.

BOOTING INTO RECOVERY

This varies from device to device, but in most cases, users must enter a key combination to put their devices into recovery mode. Some devices, for example, require you to press the power and volume up keys simultaneously while they are turned off in order to boot into the TWRP recovery. 

