

```

Send Device Cloud url = login.etherios.co.uk
Send vendor id = 0x04000026
Send device type = Linux Cloud Connector Sample
Connection Control: send redirect_report
Connection Control: send connection report
get_ip_address: Looking for current device IP
address: found
[2] entries
get_ip_address: 1: Interface name [lo] IP Address
[127.0.0.1]
get_ip_address: 2: Interface name [eth0] IP
Address
[192.168.5.128]
Send device IP address = C0 A8 05 80
Sending MAC address = 00 0C 29 32 DA 9B
Send complete
connector_tcp_communication_started
tcp_rx_keeplive_process: time to send Rx
keeplive

```

You can see Etherios Cloud Connector reporting the MAC/VendorID/IP address of the device to the cloud instance.

Now if you check Device Cloud, you can see that the device is connected (Figure 4).

If you right-click on the device, you can see its properties and execute management tasks, such as rebooting the device (Figure 5). If you want to reboot the Linux machine, then re-run Etherios Cloud Connector with root privileges.

```
#sudo ./connector
```

Now if you try to reboot from Device Cloud, your Linux PC will be rebooted. We have now successfully connected a Linux PC to Device Cloud.

Next you can add features to Etherios Cloud Connector one at a time, as follows:

- **Data points:** This is used to upload device statistics periodically, like temperature, CPU speed, etc.
 - **Device requests:** You can send messages to the device from Device Cloud or from an end application.
 - **File system:** The device's file system will be available in Device Cloud.
 - **Firmware download:** This is for upgrading firmware on the device.
 - **Remote configuration:** This is to configure the device in a remote location via Device Cloud.
 - **Send data:** This is to upload files from the device to Device Cloud; from there your application can download them at any time.
- Once your device is connected to Device Cloud using




Figure 4: Device connection status




Figure 5: Device properties




Figure 6: API explorer

Etherios Cloud Connector, you can talk to your device from any application around the world using the Web Services APIs provided in Device Cloud.

Device Cloud allows you to generate source code for the type of execution you want to do, which makes a developer's job easy. 

By: Bob Thomas

The author is an embedded open source enthusiast who works at Digi International, with expertise in Etherios Cloud Connector integration. You can reach him at Bob.thomas@digicom.com