

Dahdi versions on your system, select the correct one.

To find out which version of Dahdi is installed on your system, type `dahdi_cfg -vvv` in another Linux terminal.

5. The Wanpipe driver will now start to compile on your Linux operating system.
Press 'y' to proceed.
6. Press *Enter* to continue.
7. Press *Enter* to continue.
The example above is for an A102 2 port E1/T1 card.
8. Continue to press *Enter* when asked. Press 'y' to install Wanpipe start scripts.
9. After pressing *Enter* Wanpipe driver installation will complete on your server and now we are ready to start configuring the Sangoma hardware.
10. Press 'y' to configure all Sangoma hardware installed on the server. If you have installed Wanpipe to upgrade from a previous version, you must exit the installation process now. Because if you continue, you will overwrite all previous configurations.
11. If you have not installed your Sangoma hardware yet, you can exit the installation, install the hardware and continue by typing the `wancfg_Dahdi` command to start the configuration script.
12. The on-screen prompts that appear next will be unique to your Sangoma hardware and specific to your telecom settings. We will not show these screenshots here, but if you wish to see more details on what screens will show up next, please visit the specific `wancfg_Dahdi` pages for details.
13. After you have completed the configuration section of your Sangoma hardware, you need to restart your server.
14. Select Option 3 on your screen to save and stop Asterisk and Wanpipe (if it's already running). Any new configuration will apply only after restarting.
15. On the same screen, select Option 2 (Yes) to proceed.
16. Select Option 1 to start Wanpipe on system boot. If your server ever reboots unintentionally, you will want the driver to automatically start in order to have your server back in production without manual intervention.
17. Select Option 1 (Yes) to have `dahdi_cfg` run after the Wanpipe driver starts. This step configures Wanpipe ports for Dahdi.

You can also visit the link <http://wiki.freepbx.org/display/PC/Telephony+Cards+for+Asterisk> for

installation instructions.

After the installation and configuration of Asterisk with the Sangoma card, the LED light will glow green.

Now we begin the PRI line check and make a test call. Open the terminal and type the following:

```
#asterisk -rvvvv
and type command
pri show spans.
```

It will show that the channel is up and active (see Figure 2).

```
[root@asterisk ~]# asterisk -rvvvv
Asterisk 13.20.0, Copyright (C) 1999 - 2013 Digium, Inc. and others.
Created by Mark Spencer, markster@digium.com
Asterisk comes with ABSOLUTELY NO WARRANTY; type 'core show warranty' for details.
This is free software, with components licensed under the GNU General Public
License version 2 and other licenses; you are welcome to redistribute it under
certain conditions; type 'core show licenses' for details.
=====
Connected to Asterisk 13.20.0 currently running on asterisk (pid = 2182)
asterisk>CLI> pri
!entry, license service set show
asterisk>CLI> pri show up
spans show
asterisk>CLI> pri show spans
*0 span 1/0: in alarm, down, Active
*0 span 2/0: in, Active
asterisk>CLI>
```

Figure 2: PRI check

```
asterisk>CLI> originate dahdi/g0/7840086250 application play
Playback Playtones
asterisk>CLI> originate dahdi/g0/7840086250 application Playback hello-world
-- Requested transfer capability: none -> DTMF
-- Launching Playback(hello-world) on dahdi/12/7840086250-2022?
-- dahdi/12/7840086250-2022? Playing 'hello-world-gsm' (language 'en')
-- Hangup 'dahdi/12/7840086250-2022?'
asterisk>CLI>
```

Figure 3: PRI-playback call

Making a call

To make a call, type the following command:

```
> originate dahdi/g0/9999999999 application Playback hello-world
```

In the above command:

- `originate` is to make the call.
- `dahdi/g0/` is the channel name, followed by the phone number 9999999999.
- `application` is the command for which application or function you want to call.

You can also check the list of applications by using the command `core show applications`.

`Playback` is the application name or function name. This function is used to play a GSM or .wav file to the called number. `hello-world` is the data for the function named `Playback`. Please see Figure 3.

To make a conference call

In a terminal, run the following command:

```
> originate Dahdi/g0/7840086250 application Dial dahdi/g0/9999999999
```

In this command, we use the application name `Dial`, and data for the dial function is the channel name with the phone number `dahdi/g0/9999999999`. 

References

- [1] <http://wikipedia.com>
- [2] <http://sangoma.com>
- [3] <http://wiki.freepbx.org/display/PC/Telephony+Cards+for+Asterisk>
- [4] <http://freepbx.org>

By: Rajnish Kumar

The author has a keen interest in developing voice platform technology and is currently working at Live Digital Marketing Pvt Ltd. You can reach him at rajnishs91@gmail.com.