

3. Create a profile, remap buttons, adjust triggers/sticks, and save to the pad (Elite can store multiple profiles).

On Windows (DualSense/Edge):

1. Install Sony's PlayStation Accessories app.
2. Connect DualSense/Edge via USB or Bluetooth.
3. Update firmware; configure trigger stops, dead-zones, and save profiles (Edge).

Latency tips: Prefer 2.4 GHz dongles or Xbox Wireless over Bluetooth on PCs for competitive play; keep the receiver within line of sight and turn off unnecessary background apps.

Controller quick recipes

Make the DualSense Edge a "low-latency shooter pad" on PC

1. Plug in via USB; open PlayStation Accessories app.
2. Shorten trigger travel, increase stick response curve, disable heavy rumble, save to Profile 1.

Create an "RPG macro pad" with Xbox Elite Series 2

1. Open Xbox Accessories on PC/Xbox.
2. Map paddles to inventory/skills, add a hair-trigger profile for combat, and keep a second profile for driving games; switch on the fly.

Universal remap for a stubborn non-Steam game

1. Add the game to Steam (Add a Non-Steam Game), launch in Big Picture, then set a custom layout (gyro as mouse, paddles as hotkeys).

Home networking for smoother multiplayer

1. Use Ethernet where possible (or a Wi-Fi 6/6E router near the console/PC).
2. Target "Open" or "Moderate" NAT (Xbox calls out NAT types in Settings).
 - **Xbox:** Settings ► General ► Network settings shows NAT status and offers troubleshooting guides.
 - **PlayStation:** Sony's support covers connectivity basics; for Remote Play and certain features, NAT Type 3 may block connections.
3. Avoid DMZ unless you know what you're doing. Use UPnP or port forwarding as needed per game/platform guidance.

Troubleshooting checklist

- **No 4K120?** Verify the TV input really is HDMI 2.1 and that you used the right cable; on PS5/Xbox, confirm 120 Hz is selectable and Game Mode/ALLM is on.
- **Tearing/stuttering on PC?** Make sure G-SYNC/FreeSync is enabled in both the monitor OSD and the GPU control panel.
- **HDR looks washed out?** Re-run the console's HDR calibration;

INDIA-SPECIFIC NOTES

■ **Warranty & BIS:**

When purchasing GPUs/consoles/controllers, ensure official India warranty and BIS-compliant chargers where applicable.

■ **Power quality:**

If you game on a PC or console + TV + AVR stack, use a good surge protector or a line-interactive UPS for the PC to ride out brownouts—common in many Indian cities.

■ **Subscriptions:**

Check local INR pricing for Game Pass and PS Plus before you commit—annual/seasonal discounts are frequent on the India storefronts.

tion; on Windows, toggle HDR/Auto HDR off/on and ensure the game is actually outputting HDR.

- **Storage full?** Install a PS5-approved M.2 SSD, plug an Xbox Expansion Card, or slot a microSD Express into Switch 2.
- **Weird input feel on PC?** In Steam, open the game's Controller Layout and disable overlapping layers; on Xbox controllers, check if Xbox Accessories has an active profile with hair-trigger/curve tweaks.

Frequently asked questions

"Should I choose PS5 Pro or Xbox Series X in 2025?"

Pick PS5 Pro if you prefer Sony's exclusives and AI-assisted 4K120 feature set; pick Series X if you'll actually use Game Pass and prefer day-one first-party releases and strong backward compatibility.

"Is Switch 2 good for the TV?"

It's best as a hybrid/portable, but on a 4K TV you'll still enjoy first-party games and couch co-op; buy the Pro Controller for docked play.

"Do I really need a new GPU?"

If you already hit your monitor's refresh at your target resolution, try enabling DLSS/FSR + VRR first. Upgrade if you want to jump to 4K/120 or heavy ray tracing.

"What settings matter most on a PC?"

Enable Game Mode, Auto HDR (if you like it), G-SYNC/FreeSync, and Resizable BAR/SAM. Then tune in-game: cap fps just below your display's max and enable Reflex (GeForce) or AFME/HYPR-RX (Radeon). 