



Fig. 7: BroadCam video streaming server



Fig. 8: Self-made audio-video cable with both end male and female connectors

Sony Handycam for telecasting.)

4. Installation of video streaming server. There are a number of software available on the Internet for video streaming, but here we have used BroadCam video streaming server software because of its simplicity, easy availability and quick installation. This software is available in both free and paid versions. For software configurations, tutorial and other help, visit the link: <http://www.nchsoftware.com/broadcam/tutorial.html>

You can download this software from the link: <http://www.nchsoftware.com/broadcam/> and install it by double clicking on bsetup.exe file, and follow the on-screen instructions.

After proper installation, you will find an icon on your computer desktop with the title 'BroadCam Video Streaming Server.' Click on this icon to run the program on your PC and you will get a screen as shown in Fig. 7.

Click on the Start Server button (it has start and stop functions) to start video for live telecasting.

Click on BroadCam Video Streaming Server Live to check live input settings.

Click on Open Links option to get live streaming link and web HTML code.

5. Creating an HTML page for live web telecasting. From BroadCam video streaming server program, select Tools/Options/Web Access options and click on the link given below corresponding to Local Network option:

<http://192.168.1.99:86/live.html?src=1>

You will get a video streaming screen and HTML code for inserting on your webpage. Select HTML code, then copy and paste it on your webpage.

You can create your own webpage and paste a video streaming HTML code on it by using any HTML editor such as Microsoft FrontPage.

The HTML code for creating your webpage for live telecasting is provided in this month's EFY DVD and at source.efymag.com. You can copy this HTML code and paste it on Notepad editor and save the file name as index.html

6. Uploading an HTML page on your webpage. You can upload index.

EFY Note

The source code of this project is included in this month's EFY DVD and is also available for free download at source.efymag.com



Fig. 9: Live telecasting on Web server

html file created above by following the details as described in 'Make Your Own Web Server' article in EFY January 2013 issue, or you can use FTP for uploading index.html to your web as explained below:

1. Click on Start-> Run button on your desktop
2. Type your ftp IP address such as <ftp://210.150.160.38>
3. Enter your user name and password
4. Copy index.html file into your web wwwroot folder. (This is the root directory of your site.)
7. **Watching your live programme on your Web server.** Now, open Internet browser and type your web address: <http://www.yourwebname.com>

You will see your webpage as shown in Fig. 9

You can see the live video from here. ●

The author is a regular contributor to EFY

THE COMPLETE MAGAZINE ON OPEN SOURCE

OpenSource

For You

Your favourite Magazine on
Open Source is now on the Web, too.

LinuxForU.com

Follow us on Twitter @LinuxForU