

Fig. 2: An actual-size, single-side PCB for the visitor counter




Fig. 3: Component layout for the PCB

unit's digit and DIS2 shows the ten's digit of the count. After completion of each cycle, ten's digit advances by one. You can add more CD4026 counters with 7-segment displays for further extending the display to three digits, four digits, etc. For this, you have to connect carry-out pin 5 of each CD4026 to clock pin 1 of the next CD4026 as shown in the circuit diagram. Pin 15 of both IC1 and IC2 are connected to ground through resistor R5. A reset switch (S1) is connected to 6V for

resetting the display to '00.'

Construction and testing

An actual-size, single-side PCB for the visitor counter is shown in Fig. 2 and its component layout in Fig. 3. After assembling the circuit on a PCB, enclose it in a suitable case. Fix LED1, DIS1 and DIS2 on the front panel. Use a two-pin connector for connecting the power supply to the PCB.

This is a simple circuit and should work immediately after assembly. To

check the circuit for proper functioning, verify voltage levels on various test points as per the test point table.

Proper installation is very important. Mount LDR1 on the gate such that light falling on it is interrupted when somebody passes through the gate. We have used a fixed resistor here but, if necessary, you can use a preset in place of R2 for tuning the system to your environment. ●

The author is a hobbyist and M.Tech from Banaras Hindu University (BHU)

India's #1 Website
For **Electronics**
Engineers Working
Across The Globe

Established: 1998 | Registered Users: 300,000+

Monthly Statistics

Page Impressions:
750,000+

Unique Techies:
150,000



electronicsforu.com
If it's electronics, it's here

For any queries, please contact our team at efyeng@efyindia.com OR +91-11-26810601

EFY GROUP

MIRACLE
RAJESH KUMAR, 1988, CHANDIGARH

RIGHT SOLUTION PROVIDER



TOROIDAL TRANSFORMERS



MIRACLE ELECTRONIC DEVICES PVT LTD.

Regd. Office : # 48/1, Koriobanahalli Village, Thigalarapalya Main Road,
Peenya 2nd Stage, Bangalore - 560 058. (India)
Tel: +91 80 28362750/51 | Fax: +91 80 2836 2752
sales@miracle.net.in | www.toroidal.com