



```
// Checks for updates
```

```
pi@raspberrypi ~ $ sudo apt-get upgrade
```

```
// Installs updates if any
```

```
pi@raspberrypi ~ $ cd /etc
```

```
// This should change directory
to etc folder
```

```
pi@raspberrypi ~ /etc $ sudo chmod 666 /dev/ttyAMA0
```

```
// To add permission to use se-
// rial port
```

```
pi@raspberrypi ~ /etc $ sudo apt-get
install python-serial
```

```
// This will install serial Library
```

to Raspberry Pi

```
pi@raspberrypi ~ /etc $ cd
// This should change directory
```

```
pi@raspberrypi ~ % $ sudo apt-get install
```

```
// This will install Minicom on
```

your Raspberry Pi

<https://doi.org/10.1017/9781009051625.008>

```
// This should change direc
```

```
to Boot folder
```

```
pi@raspberrypi ~ /boot $ sudo cp
```

```
// This should make a copy of
```

cmdline.txt and rename it to cmdlinebackup.txt

```
pi@raspberrypi ~ /boot $ sudo nano
cmdline.txt
```

```
// This should open cmdline.txt
in text editor
```

```
// Remove: "console = ttyAMA0,  
115200 console = ttyl"
```

```
// Hit Ctrl + O to Save and
Ctrl + X to Exit
```

```
pi@raspberrypi ~ /boot $ cd /etc
// This should change director
```

```
pi@raspberrypi ~ $ cd /etc $ sudo cp ini
```

```
inittab.backup
// This should make a copy of
```

```
inittab and rename it to inittab.  
backup
```

```
pi@raspberrypi ~ /etc $ sudo nano
```

ttab