
Close Loop Transfer Function



Start with open loop, where plant H(s) can be a stepper motor for example, so we have

$$Y(s) = H(s) X(s)$$
 ... (1)

Now we can add a sensor to form a feedback loop as follows



So, sensor G(s) forms a feedback loop as shown in Figure 2.

$$E(s) = X(s) - G(s) Y(s)$$
 ... (2)

$$Y(s) = H(s) E(s)$$
 ... (3)

From (2) we have

$$X(s) = E(s) + G(s) Y(s) \dots (4)$$

Substitute (3), we have


$$X(s) = E(s) + G(s) H(s) E(s)$$

Hence, the transfer function is

$$\frac{Y(s)}{X(s)} = \frac{H(s)}{1 + G(s) H(s)} \dots (5)$$

Harry Li, Ph.D.

PID Control



Central Difference and Its Kernel

Forward difference:

$$FD = \frac{de(t)}{dt} \approx e(t+1) - e(t)$$


Backward difference:

$$BD = \frac{de(t)}{dt} \approx e(t) - e(t-1)$$


Central differnece:

$$CD = \frac{1}{2}(FD + BD) = \frac{1}{2}[e(t+1) - e(t-1)]$$

Map to a kernel



Map to a kernel



Map to a kernel

