Recall Hack machine instruction formet: . A - mytr: 0 ______ Send A or ALU. Where to save · C-instri » whether to jump -> load bit for PC. Minh ALU? ALU output. USE Allegister, DRegister!! History of CPUs. CPU = room sized. 1940's - 1960's - Manframes early 60s - late 70s - minicomputers. Cabinet-sized. (PDP-11, DEL VAX) 1970s+ - "microcomputers" La programmed in assembly. is Cpu an a chip. Integrated creaits (IC) Trans cont Rovers size Clock speed - Intel 8008 (1972) 3,500 transisters. 10 pm 200-800 kHz Gordon Moore -Co-fourter of Intel. - Itel 8080 (19747) 6000 6 mm 2 MHz. - Mos 6502 (1975) 4528 8pm Moore's Law I MKZ. (prediction-1965) La BBC Micro, Nintendo, Atari, Commodore 64, Apple II # of components on IC will -Itel 8088-> IBM PC. (1979) double every 2 years. 10MHz 80286 (1982) Dr. Yogan 80386 (1985) 80486 Pentium (1990's) 70MHz 100 MH/2 500 nm 200 MH2 Xeon, Celerm,

56Hz

14 nm

1980's — RISC machines "reduced instruction set compily".

Sun Microsyskin — SPARC, MIPS

ARM. Pros: low power.

Simpler.

Can: Need a good compiler.

dominates embedded device maket: gaming, phones, cors, ...