


Cross-Order Navigation

Next Order Relation

The next order relation enables moving quantities from a parent order to a child order with a properly defined level. The diagram illustrates quantities moving out of **Operation 0030** and passing to a child order to a defined level of **(1)**. There must be an existing child order that can receive quantities from a parent order from level **(1)**.



Assume a parent work order of **ABC** and a child work order of **XYZ**. In this example, the following movements of quantities would be performed:

Source			Target		
Type	Order No	Opr	Type	Order No	Opr
Parent	ABC	0010	Parent	ABC	0030
Parent	ABC	0020	Parent	ABC	0030
Parent	ABC	0030	Child	XYZ	Level 1
Child	XYZ	Level 1	Parent	ABC	0040

When defining the next order relation, the following window appears:

Set Routing Value

Relation Type

Parent

Child


Number of level:

OK

Cancel

Previous Order Relation


The previous order relation enables moving quantities from an existing parent order of a defined level to a child order. The diagram illustrates quantities moving into **Operation 0010** from a parent order-defined level of **(1)**. There must be an existing parent order that can move quantities out of level **(1)**.



Assume a parent work order of **ABC** and a child work order of **XYZ**. In this example, the following movements of quantities would be performed:

Source			Target		
Type	Order No	Opr	Type	Order No	Opr
Parent	ABC	Level 1	Child	XYZ	0010
Child	XYZ	0010	Child	XYZ	0020
Child	XYZ	0020	Parent	ABC	Level 1

When defining the previous order relation, the following window appears:



A dialog box titled "Set Routing Value" with a standard Windows-style title bar (minimize, maximize, close buttons). The dialog contains three main sections: "Relation Type" with radio buttons for "Parent" and "Child"; "Number of level:" with a text input field containing the value "1"; and "Navigation Type" with radio buttons for "Accumulate" and "Use Minimum Progress". At the bottom are "OK" and "Cancel" buttons.

Set Routing Value

Relation Type

☐ Parent ☐ Child

Number of level:

Navigation Type

☐ Accumulate ☐ Use Minimum Progress

OK Cancel