


Links Workspace Overview


The **Links** tab is a workspace available for processes, process operations, operations, and operation steps.



Available Links

Link \ Available Target	Process 	Process Operation 	Operation 	Step
Characteristic	✓	✓	✓	✓
Component	✓	✓	✓	✓
Document	✓	✓	✓	✓
Product	✓	✗	✗	✗
Resource (resource types: Generic, Building, Container, Equipment, Land, Supplier, Collection)	✓	✓	✓	✓
Specification (you can link only one specification)	✓	✓	✓	✗
Work Center (you can link only one work center)	✗	✓	✗	✗

Links Tab Right-Click Menu



Command	Description
Link	Adds a component from the list.
Preview	Previews the linked document in the appropriate viewer (for example, Adobe® Reader®).
Cut	Cuts and copies the selected link.
Copy	Copies the selected link.
Paste	Pastes the copied link.
Delete	Removes a link.
Details	Displays the properties of a resource, component, or characteristic.

To Add a Link

1. Display the link entity wizard using one of the following options:
 - ▶ Select the entity or step on the **Entity Explorer** and drag the link from the **Toolbox** to the links workspace.
 - ▶ Drag a link from the **Toolbox** to the entity in the **Entity Explorer**.
 - ▶ Use the right-click menu and choose one of the links from the **Link** option.

2. Depending on your choice, you can link:

- Characteristic
- Component
- Document
- Product
- Resource
- Specification
- Work center

3. The link is added to the workspace and to the **Recent and Favorite Items** tool pane.

To Remove a Link

Select the link and use one of the following options:

- ▶ The `DEL` key.
- ▶ The **Delete** option from the right-click menu.

To undo a link removal, select **Undo** from the **Edit** menu, use the `Ctrl+Z` keyboard shortcut, or click  (Undo) in the **toolbar**.