

Manage Task Permissions

You can add task permissions to process operations, operations, or their steps. There are four types of task permissions:

- ▶  Skill
- ▶  Role
- ▶  Employee
- ▶  Employee class

Employee class is defined by the resource class of the person type.

How To

Add a Task Permission to an Operation

Use one of the following options:

- ▶ When creating a new operation, you can add task permissions in one of the [steps](#).
- ▶ Right-click the operation in **Entity Manager** right-click menu, choose the **Properties** option, and go to the **Task Permissions** tab.
- ▶ Drag a task permission from the [toolbox](#) to the operation in the **Entity Explorer**.
- ▶ On the [operation properties](#) pane, go to the **Advanced** tab, and click **Task Permissions**.

Add a Task Permission to a Process Operation

Use one of the following options:

- ▶ Drag a task permission from the [toolbox](#) to the process operation in the **Entity Explorer**.
- ▶ On the [process operation properties](#) pane, go to the **Advanced** tab, and click **Task Permissions**.

Add a Task Permission to a Step

Use one of the following options:

- ▶ Drag a task permission from the [toolbox](#) to the step in the **Entity Explorer**.
- ▶ On the [step properties](#) pane, go to the **Advanced** tab, and click **Task Permissions**.

Copy a Task Permission

1. Use one of the following options:

- ▶ Hold the **Ctrl** key and drag the task permission from the source location to the target one in **Entity Explorer**.
- ▶ Select the link in **Entity Explorer** and:
 - ▶ Use the **Ctrl+C** and **Ctrl+V** keyboard shortcuts.
 - ▶ Choose **Copy** and **Paste** from the **Edit** menu.
 - ▶ Click  (Copy) and  (Paste) in the [toolbar](#).
 - ▶ Choose **Copy** and **Paste** from the **Entity Explorer** right-click menu.

2. A copy of the task permission appears in the target location.

Move a Task Permission

1. Use one of the following options:
 - ▷ Drag the task permission from the source location in **Entity Explorer** and drop it in the target location.
 - ▷ Select the task permission in **Entity Explorer** and:
 - ▷ Use the `Ctrl+X` and `Ctrl+V` keyboard shortcuts.
 - ▷ Choose **Cut** and **Paste** from the **Edit** menu.
 - ▷ Click  (Cut) and  (Paste) in the **toolbar**.
 - ▷ Choose **Cut** and **Paste** from the **Entity Explorer** right-click menu.
2. The link disappears from the source location and reappears in the target one.

Remove a Task Permission

1. Use one of the following options:
 - ▷ Select the task permission in the **Entity Explorer** and use one of the following options:
 - ▷ Press the `Del` key.
 - ▷ The **Delete** option from the right-click menu.
 - ▷ Select the entity or step in the **Entity Explorer**, and on the properties pane, go to the **Advanced** tab, click **Task Permissions**, select the task permission, and use **Remove**.

To undo a task permission removal, select **Undo** from the **Edit** menu, use the `Ctrl+Z` keyboard shortcut, or click  (Undo) in the **toolbar**.