AdigunPowerLab

BY HB ELEKTRONIKER

Elektrotechnischer Berechnungsbericht

Analytical electrical report — Überprüfung / Yorùbá

Projektrevision: 1 · Berechnungsversion: 1.1.0 · Schema: 1
Eingabezeitpunkt: 2026-11-05T12:00:00.000Z · Zeitzone: Europe/Berlin
Geltungsbereich / Kriterien: User-entered design criteria
2026-11-06T01:22:14.276Z · project-d8330517-31f2-4e3b-9762-b2a3cf68bf85

Berechnete Planung aus eingegebenen Daten. Keine Besichtigung, Installationsbescheinigung oder Herstellerfreigabe wird behauptet.


Berechnungsübersicht

Berechnungsübersicht	
Installierte Leistung	103,5 kW
Betriebsbedarf im eingeschalteten Zustand	103,5 kW
Bemessungsbedarf	103,5 kW
Netto-Scheinleistung	103,5 kVA
Leistungsfaktor	1
Tägliche Energieschätzung	414 kWh
Tägliche Energiekostenschätzung	124,20 €
Profilspitze	51,75 kW
Grundschwingungs-Neutralleiterstrom	0 A
Stromunsymmetrie	0 %

Eingaben für die unterstützte Berechnung sind vollständig.

Phase	Strom	Betrieb A
L1	150 A	150 A
L2	150 A	150 A
L3	150 A	150 A

Beispielhafter Tagesverlauf aus den eingegebenen Betriebsfenstern



Verbraucherliste

Verbraucher / Anzahl	Anschluss	Eingang kW	Betrieb A	Tag kWh	Herkunft
Analytical load 1 — Àtùpà × 1 · kw	single L1	2,3	10	9,2	user
Analytical load 2 — Àtùpà × 1 · kw	single L2	2,3	10	9,2	user
Analytical load 3 — Àtùpà × 1 · kw	single L3	2,3	10	9,2	user
Analytical load 4 — Àtùpà × 1 · kw	single L1	2,3	10	9,2	user
Analytical load 5 — Àtùpà × 1 · kw	single L2	2,3	10	9,2	user
Analytical load 6 — Àtùpà × 1 · kw	single L3	2,3	10	9,2	user
Analytical load 7 — Àtùpà × 1 · kw	single L1	2,3	10	9,2	user
Analytical load 8 — Àtùpà × 1 · kw	single L2	2,3	10	9,2	user
Analytical load 9 — Àtùpà × 1 · kw	single L3	2,3	10	9,2	user
Analytical load 10 — Àtùpà × 1 · kw	single L1	2,3	10	9,2	user
Analytical load 11 — Àtùpà × 1 · kw	single L2	2,3	10	9,2	user
Analytical load 12 — Àtùpà × 1 · kw	single L3	2,3	10	9,2	user

Verbraucher / Anzahl	Anschluss	Eingang kW	Betrieb A	Tag kWh	Herkunft
Analytical load 13 — Àtùpà × 1 · kw	single L1	2,3	10	9,2	user
Analytical load 14 — Àtùpà × 1 · kw	single L2	2,3	10	9,2	user
Analytical load 15 — Àtùpà × 1 · kw	single L3	2,3	10	9,2	user
Analytical load 16 — Àtùpà × 1 · kw	single L1	2,3	10	9,2	user
Analytical load 17 — Àtùpà × 1 · kw	single L2	2,3	10	9,2	user
Analytical load 18 — Àtùpà × 1 · kw	single L3	2,3	10	9,2	user
Analytical load 19 — Àtùpà × 1 · kw	single L1	2,3	10	9,2	user
Analytical load 20 — Àtùpà × 1 · kw	single L2	2,3	10	9,2	user
Analytical load 21 — Àtùpà × 1 · kw	single L3	2,3	10	9,2	user
Analytical load 22 — Àtùpà × 1 · kw	single L1	2,3	10	9,2	user
Analytical load 23 — Àtùpà × 1 · kw	single L2	2,3	10	9,2	user
Analytical load 24 — Àtùpà × 1 · kw	single L3	2,3	10	9,2	user
Analytical load 25 — Àtùpà × 1 · kw	single L1	2,3	10	9,2	user
Analytical load 26 — Àtùpà × 1 · kw	single L2	2,3	10	9,2	user
Analytical load 27 — Àtùpà × 1 · kw	single L3	2,3	10	9,2	user
Analytical load 28 — Àtùpà × 1 · kw	single L1	2,3	10	9,2	user
Analytical load 29 — Àtùpà × 1 · kw	single L2	2,3	10	9,2	user
Analytical load 30 — Àtùpà × 1 · kw	single L3	2,3	10	9,2	user

Verbraucher / Anzahl	Anschluss	Eingang kW	Betrieb A	Tag kWh	Herkunft
Analytical load 31 — Àtùpà × 1 · kw	single L1	2,3	10	9,2	user
Analytical load 32 — Àtùpà × 1 · kw	single L2	2,3	10	9,2	user
Analytical load 33 — Àtùpà × 1 · kw	single L3	2,3	10	9,2	user
Analytical load 34 — Àtùpà × 1 · kw	single L1	2,3	10	9,2	user
Analytical load 35 — Àtùpà × 1 · kw	single L2	2,3	10	9,2	user
Analytical load 36 — Àtùpà × 1 · kw	single L3	2,3	10	9,2	user
Analytical load 37 — Àtùpà × 1 · kw	single L1	2,3	10	9,2	user
Analytical load 38 — Àtùpà × 1 · kw	single L2	2,3	10	9,2	user
Analytical load 39 — Àtùpà × 1 · kw	single L3	2,3	10	9,2	user
Analytical load 40 — Àtùpà × 1 · kw	single L1	2,3	10	9,2	user
Analytical load 41 — Àtùpà × 1 · kw	single L2	2,3	10	9,2	user
Analytical load 42 — Àtùpà × 1 · kw	single L3	2,3	10	9,2	user
Analytical load 43 — Àtùpà × 1 · kw	single L1	2,3	10	9,2	user
Analytical load 44 — Àtùpà × 1 · kw	single L2	2,3	10	9,2	user
Analytical load 45 — Àtùpà × 1 · kw	single L3	2,3	10	9,2	user

Stromkreisliste

Es wurden keine Stromkreise eingegeben.

Hinweise & unvollständige Prüfungen

Bewertung	Feststellung
warning failed	L1 design current exceeds the entered 63 A supply limit.
warning failed	L2 design current exceeds the entered 63 A supply limit.
warning failed	L3 design current exceeds the entered 63 A supply limit.

Methode & Nachweise

Stiff-neutral sinusoidal AC and separate DC branch model

$P = VI \cdot PF$ (1φ); $P = \sqrt{3} \cdot V_{LL} \cdot I \cdot PF$ (3φ); $Q = \pm P \tan(\arccos PF)$; $S = \sqrt{((\Sigma P)^2 + (\Sigma Q)^2)}$; $E = \Sigma P \cdot \Delta t$

calculated · passed · Projektrevision 1

Annahmen

- Balanced supply voltages; fixed neutral; fundamental-frequency currents only.
- Duty affects energy, never on-state current. Utilization is an explicit operating assumption.
- Coincidence and growth affect design demand; they do not alter modeled energy.
- Quick estimates use one repeated 24-hour day and 30 days per month; weekday calendars and DST require calendar simulation.
- Flat-rate cost inputs are user assumptions. No normative cable/protection approval is implied.
- L–L branches contribute equal/opposite line currents; neutral excludes DC branches.

Quellenangaben

Project entered/nameplate evidence

https://www.electrical-installation.org/enwiki/Estimation_of_actual_maximum_kVA_demand

Verbrauchernachweise

Analytical load 1 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 2 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 3 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 4 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 5 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 6 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 7 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 8 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 9 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 10 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 11 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 12 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 13 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 14 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.

Analytical load 15 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 16 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 17 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 18 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 19 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 20 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 21 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 22 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 23 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 24 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 25 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 26 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 27 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 28 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 29 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 30 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 31 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 32 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 33 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 34 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 35 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 36 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 37 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 38 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 39 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 40 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 41 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 42 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 43 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 44 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 45 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.