AdigunPowerLab

BY HB ELEKTRONIKER

Elektrotechnischer Berechnungsbericht

Analytical electrical report — Überprüfung / Yorùbá

Projektrevision: 1 · Berechnungsversion: 1.0.0 · Schema: 1
Eingabezeitpunkt: 2026-11-05T12:00:00.000Z · Zeitzone: Europe/Berlin
Geltungsbereich / Kriterien: User-entered design criteria

Berechnete Planung aus eingegebenen Daten. Keine Besichtigung, Installationsbescheinigung oder Herstellerfreigabe wird behauptet.


Berechnungsübersicht

Berechnungsübersicht	
Installierte Leistung	103,5 kW
Betriebsbedarf im eingeschalteten Zustand	103,5 kW
Bemessungsbedarf	103,5 kW
Netto-Scheinleistung	103,5 kVA
Leistungsfaktor	1
Tägliche Energieschätzung	414 kWh
Tägliche Energiekostenschätzung	124,20 €
Profilspitze	51,75 kW
Grundschwingungs-Neutralleiterstrom	0 A
Stromunsymmetrie	0 %

Eingaben für die unterstützte Berechnung sind vollständig.

Phase	Strom	Betrieb A
L1	150 A	150 A
L2	150 A	150 A
L3	150 A	150 A

Beispielhafter Tagesverlauf aus den eingegebenen Betriebsfenstern



Verbraucherliste

Verbraucher / Anzahl	Anschluss	Eingang kW	Betrieb A	Tag kWh	Herkunft
Analytical load 1 — Àtùpà × 1 · kw	single L1	2,3	10	9,2	user
Analytical load 2 — Àtùpà × 1 · kw	single L2	2,3	10	9,2	user
Analytical load 3 — Àtùpà × 1 · kw	single L3	2,3	10	9,2	user
Analytical load 4 — Àtùpà × 1 · kw	single L1	2,3	10	9,2	user
Analytical load 5 — Àtùpà × 1 · kw	single L2	2,3	10	9,2	user
Analytical load 6 — Àtùpà × 1 · kw	single L3	2,3	10	9,2	user
Analytical load 7 — Àtùpà × 1 · kw	single L1	2,3	10	9,2	user
Analytical load 8 — Àtùpà × 1 · kw	single L2	2,3	10	9,2	user
Analytical load 9 — Àtùpà × 1 · kw	single L3	2,3	10	9,2	user
Analytical load 10 — Àtùpà × 1 · kw	single L1	2,3	10	9,2	user
Analytical load 11 — Àtùpà × 1 · kw	single L2	2,3	10	9,2	user
Analytical load 12 — Àtùpà × 1 · kw	single L3	2,3	10	9,2	user

Verbraucher / Anzahl	Anschluss	Eingang kW	Betrieb A	Tag kWh	Herkunft
Analytical load 13 — Àtùpà × 1 · kw	single L1	2,3	10	9,2	user
Analytical load 14 — Àtùpà × 1 · kw	single L2	2,3	10	9,2	user
Analytical load 15 — Àtùpà × 1 · kw	single L3	2,3	10	9,2	user
Analytical load 16 — Àtùpà × 1 · kw	single L1	2,3	10	9,2	user
Analytical load 17 — Àtùpà × 1 · kw	single L2	2,3	10	9,2	user
Analytical load 18 — Àtùpà × 1 · kw	single L3	2,3	10	9,2	user
Analytical load 19 — Àtùpà × 1 · kw	single L1	2,3	10	9,2	user
Analytical load 20 — Àtùpà × 1 · kw	single L2	2,3	10	9,2	user
Analytical load 21 — Àtùpà × 1 · kw	single L3	2,3	10	9,2	user
Analytical load 22 — Àtùpà × 1 · kw	single L1	2,3	10	9,2	user
Analytical load 23 — Àtùpà × 1 · kw	single L2	2,3	10	9,2	user
Analytical load 24 — Àtùpà × 1 · kw	single L3	2,3	10	9,2	user
Analytical load 25 — Àtùpà × 1 · kw	single L1	2,3	10	9,2	user
Analytical load 26 — Àtùpà × 1 · kw	single L2	2,3	10	9,2	user
Analytical load 27 — Àtùpà × 1 · kw	single L3	2,3	10	9,2	user
Analytical load 28 — Àtùpà × 1 · kw	single L1	2,3	10	9,2	user
Analytical load 29 — Àtùpà × 1 · kw	single L2	2,3	10	9,2	user
Analytical load 30 — Àtùpà × 1 · kw	single L3	2,3	10	9,2	user

Verbraucher / Anzahl	Anschluss	Eingang kW	Betrieb A	Tag kWh	Herkunft
Analytical load 31 — Àtùpà × 1 · kw	single L1	2,3	10	9,2	user
Analytical load 32 — Àtùpà × 1 · kw	single L2	2,3	10	9,2	user
Analytical load 33 — Àtùpà × 1 · kw	single L3	2,3	10	9,2	user
Analytical load 34 — Àtùpà × 1 · kw	single L1	2,3	10	9,2	user
Analytical load 35 — Àtùpà × 1 · kw	single L2	2,3	10	9,2	user
Analytical load 36 — Àtùpà × 1 · kw	single L3	2,3	10	9,2	user
Analytical load 37 — Àtùpà × 1 · kw	single L1	2,3	10	9,2	user
Analytical load 38 — Àtùpà × 1 · kw	single L2	2,3	10	9,2	user
Analytical load 39 — Àtùpà × 1 · kw	single L3	2,3	10	9,2	user
Analytical load 40 — Àtùpà × 1 · kw	single L1	2,3	10	9,2	user
Analytical load 41 — Àtùpà × 1 · kw	single L2	2,3	10	9,2	user
Analytical load 42 — Àtùpà × 1 · kw	single L3	2,3	10	9,2	user
Analytical load 43 — Àtùpà × 1 · kw	single L1	2,3	10	9,2	user
Analytical load 44 — Àtùpà × 1 · kw	single L2	2,3	10	9,2	user
Analytical load 45 — Àtùpà × 1 · kw	single L3	2,3	10	9,2	user

Stromkreisliste

Es wurden keine Stromkreise eingegeben.

Hinweise & unvollständige Prüfungen

Bewertung	Feststellung
warning failed	L1 design current exceeds the entered 63 A supply limit.
warning failed	L2 design current exceeds the entered 63 A supply limit.
warning failed	L3 design current exceeds the entered 63 A supply limit.

Methode & Nachweise

Stiff-neutral sinusoidal AC and separate DC branch model

$P = VI \cdot PF$ (1φ); $P = \sqrt{3} \cdot V_{LL} \cdot I \cdot PF$ (3φ); $Q = \pm P \tan(\arccos PF)$; $S = \sqrt{((\Sigma P)^2 + (\Sigma Q)^2)}$; $E = \Sigma P \cdot \Delta t$

calculated · passed · Projektrevision 1

Annahmen

- Balanced supply voltages; fixed neutral; fundamental-frequency currents only.
- Duty affects energy, never on-state current. Utilization is an explicit operating assumption.
- Coincidence and growth affect design demand; they do not alter modeled energy.
- Quick estimates use one repeated 24-hour day and 30 days per month; weekday calendars and DST require calendar simulation.
- Flat-rate cost inputs are user assumptions. No normative cable/protection approval is implied.
- L–L branches contribute equal/opposite line currents; neutral excludes DC branches.

Quellenangaben

Project entered/nameplate evidence

https://www.electrical-installation.org/enwiki/Estimation_of_actual_maximum_kVA_demand

Verbrauchernachweise

Analytical load 1 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 2 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 3 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 4 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 5 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 6 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 7 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 8 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 9 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 10 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 11 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 12 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 13 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 14 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.

Analytical load 15 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 16 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 17 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 18 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 19 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 20 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 21 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 22 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 23 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 24 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 25 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 26 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 27 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 28 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 29 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 30 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 31 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 32 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 33 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 34 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 35 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 36 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 37 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 38 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 39 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 40 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 41 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 42 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 43 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 44 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.
Analytical load 45 — Àtùpà: user — F01/F03 arithmetic scaled only for multipage rendering; not a surveyed installation.