

# 2.9 LEGv8 addressing for wide immediates and addresses

Although keeping all LEGv8 instructions 32 bits long simplifies the hardware, there are times where it would be convenient to have 32-bit or larger constants or addresses. This section starts with the general solution for large constants, and then shows the optimizations for instruction addresses used in branches.

#### Wide immediate operands

Although constants are frequently short and fit into the 12-bit fields, sometimes they are bigger. The LEGv8 instruction set includes the instruction move wide with zeros (MOVZ) and move wide with keep (MOVK) specifically to set any 16 bits of a constant in a register. The former instruction zeros the rest of the bits of the register and the latter leaves the remaining bits unchanged. The 16-bit field to be loaded is specified by adding LSL and then the number 0, 16, 32, or 48 depending on which quadrant of the 64-bit word is desired. These instructions allow, for example, a 32-bit constant to be created from two 32-bit instructions. The figure below shows the operation of MOVZ and MOVK





#### Addressing in branches

The LEGv8 branch instructions have the simplest addressing. They use the LEGv8 instruction format, called the *B-type*, which consists of 6 bits for the operation field and the rest of the bits for the address field. Thus,

```
B 10000 // go to location 10000ten
```

could be assembled into this format (it's actually a bit more complicated, as we will see):

| 5      | 10000 <sub>ten</sub> |
|--------|----------------------|
| 6 bits | 26 bits              |

where the value of the branch opcode is 5 and the branch address is  $10000_{\text{ten}}$ .

Unlike the branch instruction, a conditional branch instruction can specify one operand in addition to the branch address. Thus,

```
CBNZ X19, Exit // go to Exit if X19 \neq 0
```

is assembled into this instruction, leaving only 19 bits for the branch address:

| 181    | Exit    | 19     |  |  |
|--------|---------|--------|--|--|
| 8 bits | 19 bits | 5 bits |  |  |

This format is called *CB-type*, for conditional branch. (The conditional branch instructions that rely on condition codes also use the CB-type format, but they use the final field to select among the many possible branch conditions.)

If addresses of the program had to fit in this 19-bit field, it would mean that no program could be bigger than 2<sup>19</sup>, which is far too small to be a realistic option today. An alternative would be to specify a register that would always be added to the branch offset, so that a branch instruction would calculate the following:

Program counter = Register + Branch offset

This sum allows the program to be as large as 2<sup>64</sup> and still be able to use conditional branches, solving the branch address size problem. Then the question is, which register?

The answer comes from seeing how conditional branches are used. Conditional branches are found in loops and in *if* statements, so they tend to branch to a nearby instruction. For example, about half of all conditional branches in SPEC benchmarks go to locations less than 16 instructions away. Since the *program counter* (PC) contains the address of the current instruction, we can branch within  $\pm 2^{18}$  words of the current instruction if we use the PC as the register to be added to the address. Almost all loops and *if* statements are much smaller than  $2^{18}$  words, so the PC is the ideal choice. This form of branch addressing is called *PC-relative addressing*.

PC-relative addressing: An addressing regime in which the address is the sum of the program counter (PC) and a constant in the instruction

Like most recent computers, LEGv8 uses PC-relative addressing for all conditional branches, because the destination of these instructions is likely to be close to the branch. On the other hand, branch-and-link instructions invoke procedures that have no reason to be near the call, so they normally use other forms of addressing. Hence, the LEGv8 architecture offers long addresses for procedure calls by using the B-type format for both branch and branch-and-link instructions.

Since all LEGv8 instructions are 4 bytes long, LEGv8 stretches the distance of the branch by having PC-relative addressing refer to the number of *words* to the next instruction instead of the number of bytes. Thus, the 19-bit field can branch four times as far by interpreting the field as a relative word address rather than as a relative byte address: ±1 MB from the current PC. Similarly, the 26-bit field in branch instructions is also a word address, meaning that it represents a 28-bit byte address.

The unconditional branch is also PC-relative, which means it can branch ±128 MB from the current PC.

#### Example 2.9.1: Showing branch offset in machine language.

The while loop was compiled into this LEGv8 assembler code:

```
Loop: LSL X10, X22, #3  // Temp reg X10 = 8 * i

ADD X10, X10, X25  // X10 = address of save[i]

LDUR X9, [X10,#0]  // Temp reg X9 = save[i]

SUB X11, X9, X24  // X11 = save[i] - k

CBNZ X11, Exit  // go to Exit if save[i] ≠ k (X11 ≠ 0)

ADDI X22, X22,#1  // i = i + 1

B  Loop  // go to Loop
```

Exit:

If we assume we place the loop starting at location 80000 in memory, what is the LEGv8 machine code for this loop?

#### Answer

The assembled instructions and their addresses are:

| 80000 | 1691 | 0  | 3 | 22 | 10 |
|-------|------|----|---|----|----|
| 80004 | 1112 | 25 | 0 | 10 | 10 |
| 80008 | 1986 | 0  | 0 | 10 | 9  |
| 80012 | 1624 | 24 | 0 | 9  | 11 |
| 80016 | 181  |    | 3 |    | 11 |
| 80020 | 580  |    | l | 22 | 22 |
| 80024 | 5    | -6 |   |    |    |
| 80028 |      |    |   |    |    |

Remember that LEGv8 instructions have byte addresses, so addresses of sequential words differ by 4, the number of bytes in a word, and that branches multiply their address fields by 4, the size of

LEGv8 instructions in bytes. The CBNZ instruction on the fifth line adds 3 words or 12 bytes to the address of the instruction, specifying the branch destination relative to the branch instruction (12 + 80016) and not using the full destination address (80028). The branch instruction on the last line does a similar calculation for a backwards branch (-24 + 80024), corresponding to the label Loop.

#### Hardware/Software Interface

Most conditional branches are to a nearby location, but occasionally they branch far away, farther than can be represented in the 19 bits of the conditional branch instruction. The assembler comes to the rescue just as it did with large addresses or constants: it inserts an unconditional branch to the branch target, and inverts the condition so that the conditional branch decides whether to skip the unconditional branch.

### Example 2.9.2: Branching far away.

Given a branch on register x19 being equal to register zero,

CBZ X19, L1

replace it by a pair of instructions that offers a much greater branching distance.

#### Answer

These instructions replace the short-address conditional branch:

```
CBNZ X19, L2
B L1
L2:
```

#### LEGv8 addressing mode summary


Multiple forms of addressing are generically called *addressing modes*. The figure below shows how operands are identified for each addressing mode. The addressing modes of the LEGv8 instructions are the following:


- 1. Immediate addressing: The operand is a constant within the instruction itself
- 2. Register addressing: The operand is a register
- 3. Base addressing / displacement addressing. The operand is at the memory location whose address is the sum of a register and a constant in the instruction
- 4. PC-relative addressing: The branch address is the sum of the PC and a constant in the instruction

Addressing mode: One of several addressing regimes delimited by their varied use of operands and/or addresses.

# Figure 2.9.1: Illustration of the four LEGv8 addressing modes (COD Figure 2.19).

The operands are shaded in color. The operand of mode 3 is in memory, whereas the operand for mode 2 is a register. Note that versions of load and store access bytes, halfwords, words, or doublewords. For mode 1, the operand is part of the instruction itself. Mode 4 addresses instructions in memory, with mode 4 adding a long address shifted left 2 bits to the PC. Note that a single operation can use more than one addressing mode. Add, for example, uses both immediate (ADDT) and register (ADD) addressing.





The operand is a constant within the instruction itself.

The operand is a register.

The operand is at the memory location whose address is the sum of a register and a constant in the instruction.

The branch address is the sum of the PC and a constant in the instruction.

Rese

#### **Decoding machine language**

Sometimes you are forced to reverse-engineer machine language to create the original assembly language. One example is when looking at "core dump". The figure below shows the LEGv8 encoding of the opcodes for the LEGv8 machine language. This figure helps when translating by hand between assembly language and machine language.

Figure 2.9.2: LEGv8 instruction encoding (COD Figure 2.20).

The varying size opcode values can be mapped into the space they occupy in the widest opcodes. By looking at the first 11 bits of the instruction and looking up the value, you can see which instruction it refers to.

| In advantage | Oncode      | Opcode | 11-bit ope | Instruction |             |  |
|--------------|-------------|--------|------------|-------------|-------------|--|
| Instruction  | Opcode      | Size   | Start End  |             | Format      |  |
| В            | 000101      | 6      | 160        | 191         | B - format  |  |
| STURB        | 00111000000 | 11     | 448        |             | D - format  |  |
| LDURB        | 00111000010 | 11     | 450        |             | D - format  |  |
| B.cond       | 01010100    | 8      | 672        | 679         | CB - format |  |
| ORRI         | 1011001000  | 10     | 712        | 713         | I - format  |  |
| EORI         | 1101001000  | 10     | 840        | 841         | I - format  |  |
| STURH        | 01111000000 | 11     | 960        |             | D - format  |  |
| LDURH        | 01111000010 | 11     | 962        |             | D - format  |  |
| AND          | 10001010000 | 11     | 1104       |             | R - format  |  |
| ADD          | 10001011000 | 11     | 1112       |             | R - format  |  |
| ADDI         | 1001000100  | 10     | 1160       | 1161        | I - format  |  |
| ANDI         | 1001001000  | 10     | 1168       | 1169        | I - format  |  |
| BL           | 100101      | 6      | 1184       | 1215        | B - format  |  |
| ORR          | 10101010000 | 11     | 1360       |             | R - format  |  |
| ADDS         | 10101011000 | 11     | 1368       |             | R - format  |  |
| ADDIS        | 1011000100  | 10     | 1416       | 1417        | I - format  |  |
| CBZ          | 10110100    | 8      | 1440       | 1447        | CB - format |  |
| CBNZ         | 10110101    | 8      | 1448       | 1455        | CB - format |  |
| STURW        | 10111000000 | 11     | 1472       |             | D - format  |  |
| LDURSW       | 10111000100 | 11     | 1476       |             | D - format  |  |
| STXR         | 11001000000 | 11     | 1600       |             | D - format  |  |
| LDXR         | 11001000010 | 11     | 1602       |             | D - format  |  |
| EOR          | 11001010000 | 11     | 1616       |             | R - format  |  |
| SUB          | 11001011000 | 11     | 1624       |             | R - format  |  |
| SUBI         | 1101000100  | 10     | 1672       | 1673        | I - format  |  |
| MOVZ         | 110100101   | 9      | 1684       | 1687        | IM - format |  |
| LSR          | 11010011010 | 11     | 1690       |             | R - format  |  |
| LSL          | 11010011011 | 11     | 1691       |             | R - format  |  |
| BR           | 11010110000 | 11     | 1712       |             | R - format  |  |
| ANDS         | 11101010000 | 11     | 1872       |             | R - format  |  |
| SUBS         | 11101011000 | 11     | 1880       |             | R - format  |  |
| SUBIS        | 1111000100  | 10     | 1928       | 1929        | I - format  |  |
| ANDIS        | 1111001000  | 10     | 1936       | 1937        | I - format  |  |
| MOVK         | 111100101   | 9      | 1940       | 1943        | IM - format |  |
| STUR         | 11111000000 | 11     | 1984       |             | D - format  |  |
| LDUR         | 11111000010 | 11     | 1986       |             | D - format  |  |

## Example 2.9.3: Decoding machine code.

What is the assembly language statement corresponding to this machine instruction?

8b0f00130<sub>hex</sub>

#### Answer

The first step in converting hexadecimal to binary:

1000 1011 0000 1111 0000 0000 0001 0011

To know how to interpret the bits, we need to determine the instruction format, and to do that we first need to find the opcode field. The problem is that the opcode varies from 6 bits to 11 bits depending on the format. Since opcodes must be unique, one way to identify them is to see how many 11-bit opcodes do the shorter opcodes correspond.

For example, the branch instruction **B** use a 6-bit opcode with the value:

00 0101

Measured in 11-bit opcodes, it occupies all the opcode values from

00 0101 00000

to

00 0101 11111

That is, if any 11-bit opcode had a value in that range, such as

#### 00 0101 00100

it would conflict with the 6-bit opcode of branch.

The figure above lists the instructions in LEGv8 in numerical order by opcode, showing the range of the 11-bit opcode space they occupy. For example, branch goes from 160 to 191, which is the decimal version of the bit patterns above. To determine the opcode, you just take the first 11 bits of the instruction, convert it to decimal representation, and then look up the table to find the instruction and its format

In this example, the tentative opcode field is then  $10001011000_{two}$ , which is  $1112_{ten}$ . When we search the figure above, we see that opcode corresponds to the ADD instruction, which uses the R-format. Thus, we can parse the binary format into fields listed in the figure below:

op Rm shamt Rn Rd 10001011000 00101 000000 01111 10000


We decode the rest of the instruction by looking at the field values. The decimal values are 5 for the Rm field, 15 for Rn, and 16 for Rd (shamt is unused). These numbers represent registers x5, x15, and x16. Now we can reveal the assembly instruction:

ADD X16, X15, X5

Figure 2.9.3: LEGv8 instruction formats (COD Figure 2.21).

| Name       |    | Fields       |              |             |        |                       |                           | Comments                                |
|------------|----|--------------|--------------|-------------|--------|-----------------------|---------------------------|---|
| Field size |    | 6 to 11 bits | 5 to 10 bits | 5 or 4 bits | 2 bits | 5 bits                | 5 bits                    | All LEGv8 instructions are 32 bits long |
| R-format   | R  | opcode       | Rm           | shamt       |        | Rn                    | Rd                        | Arithmetic instruction format           |
| I-format   | 1  | opcode       | immediate    |             |        | Rn                    | Rd                        | Immediate format                        |
| D-format   | D  | opcode       | address op2  |             | op2    | Rn                    | Rt                        | Data transfer format                    |
| B-format   | В  | opcode       | address      |             |        |                       |                           | Unconditional Branch format             |
| CB-format  | СВ | opcode       | address Rt   |             |        |                       | Conditional Branch format |   |
| IM-format  | IM | opcode       | immediate Rd |             |        | Wide Immediate format |                           |   |

The figure above shows all the LEGv8 instruction formats. COD Figure 2.1 (LEGv8 assembly language revealed in this chapter) shows the LEGv8 assembly language revealed in this chapter. The next chapter covers LEGv8 instructions for multiply, divide, and arithmetic for real numbers.



### Elaboration

An easy-to-understand way for hardware to figure out the format of the instruction in parallel is to think of the hardware as having a read-only memory whose address size matches the largest opcode and whose content tells the hardware what to do for the specific instruction. Thus, instructions like add (ADD) that have an 11-bit opcode have a single entry in the memory, but instructions like branch (B) with a 6-bit opcode have many redundant copies. In fact, B has  $2^{11}/2^6 = 2^5$  or 32 entries. A more efficient hardware structure than a read-only memory that will accomplish the same task is a programmable-logic array (PLA), which essentially modifies the address decoder so that there is a single entry for every opcode, no matter its size (see COD Appendix B (Graphics and Computing GPUs)).