

## WonkyStuff Core1 Assembly Instructions

Thanks for buying the WonkyStuff **core1** board. The **core1** is designed as a simple audio generation device which can be reprogrammed. There are four controls (the function of which will depend on the programming) and a single, mono, audio output. The **core1** is designed to run from 4.5v - applying any more is likely to cause damage to the chips (the other components will be fine).

These instructions are a work in progress. If they are unclear, or there are any mistakes, or you just want to say 'hello', please email us at info@wonkystuff.net, or message us via facebook or twitter.

## **Parts List**

Before starting, make sure that you have all of the parts listed below. The chips are not big fans of static electricity, so take care when handling them (they're quite robust in our experience, but take care nonetheless).

Label	Part	Description
U1	ATTiny85-20	Main processor (pre-programmed as dr1a)
U2	MCP6002	Dual Op-Amp
U3	n/a	Not yet used
VR0-3	10k Potentiometer x4	Interaction!
R1	n/a	Not yet used
R2	15k	Resistor (brown/green stripes)

R3	8.2k	Resistor (grey/red stripes)
C1	1nF	Capacitor (marked 102)
C2	470pF	Capacitor (marked 471)
P1	Power connector	apply 4.5v here
J1	3.5mm jack	Audio Output
B1	Battery pack	Takes 3 AAA batteries (not included)
-	2 IC sockets	
-	PCB	a double-sided Printed Circuit Board

You'll also need a soldering iron, some solder, a pair of wire cutters and a space to work in.

## **Assembly**

**Core1** requires components to be placed on both sides of the PCB, the white text/outline will indicate the correct placing of each component.

The general procedure with the assembly is to work in component-height order, so, let's start!

- 1. Position the PCB so that the *Designed by...* text is uppermost:
  - i. Solder R2 and R3;
  - ii. Solder C1 and C2;
  - iii. Solder IC sockets into positions U1 and U2, taking care to match the notch in the socket with the symbol on the PCB.
  - iv. Solder the power connector so that it protrudes over the edge of the PCB
- 2. Turn over the PCB:
  - i. Solder J1 into place take care that the pins go into the correct holes (and not into R1):
  - ii. Solder the four potentiometers into place (the large tabs may need a slight squeeze for them to go into the holes correctly). The tabs are there for mechanical support, don't forget to solder them!
- 3. Turn the board over again and insert U1 and U2 into their respective sockets (the legs may need a little squeeze to make them line up).

And that's it for assembly.

## Sound!

- 1. Insert 3 AAA batteries into the battery holder;
- 2. Connect the audio output to your audio device (e.g. a mixer);
- 3. Rotate all of the controls fully counter-clockwise;
- 4. Attach the battery pack to the board.

Now there should be a low-frequency sound coming from the output. Altering VR1 will change the waveform (there are 8 different shapes). VR2 changes the fundamental frequency, and VR3 changes the slave frequency - play about and see what sounds good. VR0 causes the waveform to change randomly - the frequency of change depends on how far clockwise VR0 is turned.