


IWA - OPERATION MANUAL

WARNING!

Do Not Bridge Amplifier Channels. This Will Damage The Amplifier and Void Warranty.

CONFIGURATION: (standard) Line Level input and DC power input on front panel, speaker outputs in back.

NOTE: The IWA amplifier series allows for multiple configurations of the inputs and outputs to be tailored for specific customer applications. This is one of the many options.



- 1) Set-up the equipment as shown above in the diagram.
- 2) Observe polarity when connecting the speakers (positive to red and negative to black of the speaker terminals).
- 3) Be sure to use the supplied power supply. Usage of different power supplies will void warranty and can damage the products.
- 4) Congratulations! You have just installed the best sounding amplifier you will ever hear. Enjoy the music.