



## Installation Process

⚠ Note: This document has been superseded by the *Smoke Alarm Manual.docx* and *Sensor Hub Manual.docx* on OneDrive: [User Manuals](#)

1. Physically install the Hub and power it on.
2. Open up the mobile Trader app, log in and proceed with the job assigned.
3. Scan QR code to connect the Hub.
4. The blue comms light on the Hub (the far right one) will be flashing. Wait around three minutes until it goes solid blue.
5. Tap refresh in app and it'll display as connected if it doesn't refresh automatically.
6. Double-tap Alarm's physical TEST button within 1s to put that alarm into pairing mode. The orange light will flash for two minutes while it's in pairing mode.
7. Scan and add that Alarm in the mobile app, the Alarm will beep to indicate success.
8. Repeat Steps 6 & 7 for other Alarms.
9. Done! Take photos and tap complete job.

---

Previous installation notes below with more technical details:

Installation is two-part, with the Hub being installed initially, then alarms.

### Hub

- **Electrician** logs into mobile app.
- **Agent** assigns *Job* (on a *Property*) to an **electrician**.
- **Electrician** receives push notification about *Job*.
- **Electrician** takes hardware to location and opens app ready to install.
- **Electrician** scans Hub QR code with app and installs Hub hardware, nominally behind the fridge.



AAAABBBBCCCC

- **Electrician** takes photos of Hub after it's installed.
- API activates SIM card and polls `VERIFY` command to Hub until a response is received.
- After 5-10 minutes, the SIM card will be active and the API will receive a `VERIFY` response from the Hub to indicate it's now online.

### Alarms

- After Hub is installed, **electrician** will scan the alarm QR code with the app and install alarm as required.



AAAABBBBCC01

- API will send `ADD` command to Hub, which will then link the alarm to that Hub taking around 10 seconds.
- **Electrician** will repeat this process to add additional alarm(s) in property.
- **Electrician** takes photos of alarms after they're installed.

- After all alarms are installed, **electrician** will run a Test, where the API will send the Hub a **TEST** event - and each alarm will sound in sequence.
- With a positive response to the **TEST** event, installation is done and the **electrician** taps confirm to sign off the *Job*.