STM hands-on session

Paolo Burgio paolo.burgio@unimore.it






Programming is a skill best acquired by practice and example rather than from books.



Our guy (IoT node)

2x USB (Use this one!)





Software

Micro-kernel

> No OS, need to flash al memory regions

ST proprietary

- > STM32 CubeIDE
- > Debug via STLink (won't see this)

How to work

- No way is to compile our code directly on IoT Node
- > Cross-compilation *via* the CubeIDE
- > Flash the whole OS+program via USB

A simple application




Create a new "Blink" project

- > File -> New Project
- > Then. Select the MCU (or the board)
- > **DO NOT initialize the peripherals in default mode!!! (**for this time..)

IDE STM32 Project

Target Selection

Select STM32 target or STM32Cube example





IDE


```
workspace_1.10.1 - Blink/Core/Src/main.c - STM32CubeIDE
<u>File Edit Source Refactor Navigate Search Project Run Window Help</u>
Project Explorer ×
                                  i main.c × III Blink.ioc
                                         /* USER CODE END SysInit */
🕶 🔤 Blink
                                    83
                                    84
  Binaries
                                    85
                                        /* Initialize all configured peripheral
  Mincludes
                                    86
                                         MX GPIO Init();
  Main file (the one)
                                         /* USER CODE BEGIN 2 */
                                    87
       with "main")
                                    88
                                    89
                                         /* USER CODE END 2 */
        main.c
                                    90
                                         /* Infinite loop */
                                    91
         <u>ा sumb≥ı4xx_nal_msp.c</u>
                                         /* USER CODE BEGIN WHILE */
                                    92
        stm32l4xx it.c
        syscalls.c
                                         while (1)
         sysmem.c
                                                           Initialization/setup +
         system_stm32l4xx.c
                                           /* USER CO
                                                               infinite loop
    Startup
                                                              (Arduino-like)
                                           /* USER CODE
    Driverc
      Some generated
                                           // write pin sta
     files. Do not touch
          them...
```



Configure LEDs


We want to create an alias for GPIOs.

So we don't need to change code when we change LEDs






Let's configure PA5





Leds and GPIOs






General Purpose I/O Ports

Our interface towards the external world

- > Also supports Arduino Uno R3
- > Let's skip this...

GPIOs are divided into two **board blocks**, and five **SoC ports**

- > CN1,2
- > Port A, B, C, D, E
- > (not all ports are available on the board!!!)





Write on GPIO PINs

```
stm3214xx hal gpio.h
```

```
// Write pin state (with alias)
HAL_GPIO_TogglePin(LED1_GPIO_Port, LED1_Pin);

// Write pin state (with direct mapping)
//HAL_GPIO_TogglePin(GPIOA, GPIO_PIN_5);

// Synchronous delay for 500 ms
HAL_Delay(500);
```

<u>·····</u>: 📬 ▼ 🖟 🐚 🗞 ▼ 🐔 ▼ 🛗 : 💣 ▼ 🛍 ▼ 🧗 ▼ 🧿 🗖 Project Explorer 🗡 ✓ III Blink > **&** Binaries > 🔊 Includes > □ Inc ✓ ► Src > 🖟 main.c > le stm32l4xx_hal_msp.c > stm32l4xx it.c > 🖻 syscalls.c > **l** sysmem.c > 🖻 system_stm32l4xx.c > ≥ Startup lt's a generated file!! ex.h > li stm32l4x dma.h exti.h > li stm32l4xx > h stm32l4xx flash ex.h > lash_ramfunc.h > In stm32l4xx h flash.h > li stm32l4xx_hal_gpio_ex.h > ln stm32l4xx_hal_gpio.h > la stm32l4xx hal i2c ex.h > 16 stm32l4xx hal i2c h

The Fair Source velacion inavidate segich Flolect val






Breadboard

Provides electrical connectivity

- > Vertical vs. horizontal rails
- > (Typically, power vs other)
- > Can use jumper wires






Breadboard

The two sides of the + and - rails are wired together

> Typically, used for power/GND

Brought to the internal rails with jumper wires

> Where core/chip and other stuff reside






Finally...LEDs

Light Emitting Diodes

- > You feed with electrons; they light up
- > They have a side!!!!
- > They need a resistance to lower the charge


Wrong wiring => you burn them...







E/E system






Let's play with Pins


PA5 is also in board pinout

- > Connect our led to them
- > PB14 is not...






Exercise



> Implement the Moore machine of the FSM that understands whether a words is from L

"Identify even sequences of a (even empty), followed by one, or more, or no, b, ended by c"

- ..and turns on the corresponding led color
 - Blue => GPIO 0
 - Red (error state) => GPIO 1
 - Yellow => GPIO 2
 - **Green** => GPIO 3






Serial communication

Universal asynchronous receiver-transmitter — UART


"Asynchronous" -> One channel for TX, one channel for RX

USART Universal Synchronous/Asynchronous Receiver/Transmitter





Configure USART1



- > PB6 for Tx
- > PB7 for Rx



Write code

Copy-paste this in your main loop



System header

```
/**
  * @brief Send an amount of data in blocking mode.
  * [...]
  * @param huart UART handle.
  * @param pData Pointer to data buffer (u8 or u16 data elements).
  * @param Size Amount of data elements (u8 or u16) to be sent.
  * @param Timeout Timeout duration.
  * @retval HAL status
  */
HAL_StatusTypeDef HAL_UART_Transmit(UART_HandleTypeDef *huart, const uint8_t *pData, uint16_t Size, uint32_t Timeout);
```

> Returns "check"




On your machine... (1)

First, test with a "standard" serial Monitor

- > Linux
 - sudo apt install minicom
 - Serial/USB ports are typically /dev/ttySOMETHING
- > Windows
 - Putty
 - Serial/USB ports are COMx

115200 Baud, no parity, 8 bit





On your machine... (2)

Programmatically read from serial/USB

- > C++
 - https://github.com/imabot2/serialib
- > Python
 - pySerial



References



Course website

http://hipert.unimore.it/people/paolob/pub/Industrial_Informatics/index.html

My contacts

- paolo.burgio@unimore.it
- > http://hipert.mat.unimore.it/people/paolob/

Resources

- > A "small blog -> http://www.google.com
- > Serial comms
 - https://wiki.st.com/stm32mcu/wiki/STM32StepByStep:Step3_Introduction_to_the_UART
 - https://github.com/imabot2/serialib