# PLC programming


Paolo Burgio paolo.burgio@unimore.it







### Structure of a PLC





## PLC programming with IEC 61131

First attempt of standardization => <u>IEC 61131-3 standard</u>

- > yr 1993, latest rev 2013
- > Before that, "the fish market" of languages
- > Still, Ladder was a prominent one...but everyone had its own variant!!

States that there are 5 "standard" ways of programming PLCs

- > Ladder diagram
  - Description of electrical wiring, designed for non-informatics
- > Function Block Diagram FBD
  - From electronics
- > Sequential Functional Chart SFC
  - Petri-net style
- > Instruction List IL
  - ASM-like
- > Structured Text ST
  - Similar to Pascal/VB



### IEC 61131

Covers the complete lifecycle of PLC modules and sw development for PLC PLC programming

- > Part 1: definition of <u>terminology</u> and concepts
- > Part 2: electronic and mech equipment and verification/testing
- > Part 3: programming languages (5 types)
- > Part 4: how to choose, install and maintain
- > Part 5: how to <u>communicate</u> (MMS Manufacturing Messaging Specification)
- > Part 6: communication via fieldbusses/other ind. standards
- > Part 7: fuzzy control (won't see this..if you don't want)
- > Part 8: sw dev guidelines







## Ladder diagrams

Possible circuit to power on a motor

- > Left: electrical diagram; right: Ladder
- > Does it remind of something...?








## Ladder programs

Writing a program is as easy as writing a switching circuit

- Vertical lines are power rails, and power flows from topleft to bottom-right
  - So does "program flow"
- Horizontal lines (<u>rungs</u>) connect power rails
  - Every rung starts with one or more inputs, and ends with exactly one output
- Typical exec time: 1ms for 1k bytes of program, so usually approx 10-50ms

#### Program flow

- > Store input status in mem
- Read inputs from memory, run program, store out in mem
- > Update all outputs






## Ladder symbols

- > Power rails (Vert lines)
- > Rungs (Horiz lines)








- Normally open (NO) contact
- > Normally closed (NC) contact



> Output coil (from a lamp, a motor...)










## Example: a (lamp?) switch

> When a NO contact is closed, the attached coil propagates the signal



> When a NC contact is opened, the attached coil propagates the input signal







# Structured Text



### Structured text

- > Inspired by Pascal language, also Basic and VB programmer might find it familiar
- Procedural language (can define Functions, or Function Blocks)
- Or define a Program (and call it from within your Application MainTask)
  - Can have multiple programs...you must have one call for one program!

Can also comment code...

```
(* This is a comment! *)

(* This is a
   multi-line
   comment! *)
```



## Defining variables

#### Can also initialize them

> Don't forget semicolon;

IEC 61131.3 defines several datatypes

> Few examples

Contact1: BOOL;
Contact2: BOOL := FALSE;

IEC Data Type	Format	Range
SINT	Short Integer	-128 127
INT	Integer	-32768 32767
DINT	Double Integer	-2^31 2^31-1
UINT	Unsigned Integer	0 2^16-1
BOOL	Boolean	1 bit
BYTE	Byte	8 bits
WORD	Word	16 bits
STRING	Character String	'My string'
TIME	Duration of time after an event	<b>T#</b> 10d4h38m57s12ms <b>TIME#</b> 10d4h38m
DATE	Calendar date	<b>D#</b> 1989-05-22 <b>DATE#</b> 1989-05-22
REAL	Real Numbers	±10 ^ ±38



## Variables: simple operations

> Assigning immediate vals to variables

```
Contact1 := FALSE;
Input1 := 11;
Output1 := 5;
```

Contact1: BOOL;
Input1: INT;
Output1: BYTE;

> Also, with operators in R-values

```
Output1 := Input1 - Output1 / ( Input6 + 3 );
```





# Structured Text Operators (and their priority)

Operators	Description
( )	Parenthesized (brackets) expression
Function ( )	List of parameters of a function
**	Power
-, NOT	Negation, Boolean NOT
* , / , MOD	Multiplication, division, modules operations
+, -	Add, subtract
< , > , <= , >=	Comparison
=, <>	Comparison
AND, OR	Boolean operator
XOR	Exclusive OR
OR	Boolean OR

orecedence



## Define your own datatypes

```
(* Enum-like datatype *)
TYPE Motor_State:( Stopped, Running );
END_TYPE;
```

```
(* Analog value datatype *)
TYPE Pressure: REAL;
END_TYPE;
```




### Variables: nomenclature

- > ST is not case sensitive; in case you might want to use capital letter for clarity
- > Use the AT keyword to fix the memory location of a variable

```
Contact1: BOOL AT %MX100; (* Internal memory Bit at address 100 *)

Input1: INT AT %IW200; (* Input memory Word at address 200 *)

Output1: BYTE AT %OB300; (* Output memory Byte at address 300 *)
```





### If-Then-Else


```
IF Contact1 = TRUE THEN;
  Coil1 := TRUE;
ELSE;
  Coil1 := FALSE;
END_IF;
```

```
IF NOT Contact1 = TRUE;
   Coil1 := TRUE;
END_IF;
```

```
IF Contact1 = TRUE OR Input1 = 11;
  Coil1 := TRUE;
END_IF;
```



## Ladder vs. ST



```
Valve1 := Sensor1;
IF Sensor1 THEN;
 Valve1 := 1;
END_IF;
```





### Switch-case

- Multiple instructions on the same line
- > Default with ELSE keyword
- > Can also use ranges

```
CASE (State) OF
  1: NextState := 2; ERROR := FALSE;
  2: NextState := 3; ERROR := FALSE;

ELSE
  NextState := 4; ERROR := TRUE;
END_CASE;
```

```
CASE (Temperature) OF
   0...40: Furnace_switch := ON;
   40...100: Furnace_switch := OFF;
END_CASE;
```



### Loops

> For, While-Do, Repeat-Until

```
(* do...
    while (input1 < 3
        && input2 == 5); *)
Output1 := 0;
REPEAT
DO
    Output1 := Output1 + 1;
UNTIL Input1 < 3 AND Input2 = 5
END_REPEAT;</pre>
```



## **Defining Programs**

Read (input vars) – Exec – Write (output vars) paradigm


```
(* ... *)

VAR (* Input type, and datatype,
implicit by memory *)
  Temperature AT $IW100;
END_VAR;
(* ... *)
```

```
PROGRAM Example
VAR IN (* Input *)
  Temperature: INT;
  Humidity: REAL;
END VAR;
VAR IN (* Input *)
  Speed: INT = 50;
END VAR;
VAR OUT (* Outputs *)
 Motor speed: REAL;
END VAR;
(* Instructions here *)
END PROGRAM;
```




### Exercise



Implement the Moore machine of the FSM that understands whether a words is from L


> "Identify even sequences of a (even empty), followed by one, or more, or no, b, ended by c"

- ...and turns on the corresponding led color
  - Red (error state)
- How do we give input?
  - 3 inputs => 3 "push buttons"






## Exercise (start from this..)



> Implement the Moore machine of the FSM that understands whether a words is from L

"Two a (or no a) followed by one c"

- > ...and turns on the corresponding led color
  - Red (error state)
- > START EVEN SIMPLER!
  - "...that detects c"
  - "...that detects a followed by c"



# Logic blocks




## (Unnecessary) brief recap


#### Logic functions

- > Already seen in previous courses
- > Express Boolean logics, adders, latches, ...

#### Example: Logical AND





A	В	Output
0	0	0
0	1	0
1	1	1
1	0	0







### Ladder and ST AND









A	В	Output
0	0	0
0	1	0
1	1	1
1	0	0







### Ladder and ST OR









A	В	Output
0	0	0
0	1	1
1	1	1
1	0	1







## Ladder and ST NOT








A	Output
0	1
1	0






## Boolean algebra











$$\rightarrow \overline{A} = Out$$



A	В	A * B
0	0	0
0	1	0
1	1	1
1	0	0



### Ladder and ST NAND



```
IF NOT Sensor1 OR NOT Sensor2 THEN;
  Valve1 := TRUE;
ELSE
  Valve1 := FALSE;
END_IF;
```


```
A Output
```


A	В	Output
0	0	1
0	1	1
1	1	0
1	0	1


```
IF Sensor1 AND Sensor2 THEN;
  Valve1 := FALSE;
ELSE
  Valve1 := TRUE;
END_IF;
```



### Ladder and ST NOR









A	В	Output
0	0	1
0	1	0
1	1	0
1	0	0


```
IF Sensor1 OR Sensor2 THEN;
   Valve1 := FALSE;
ELSE
   Valve1 := TRUE;
END_IF;
```



### Ladder and ST XOR







A	В	Output
0	0	0
0	1	1
1	1	0
1	0	1




## Latching

- > We often need to store in memory a value (e.g. a bit)
  - I.e., to store a **state**
- Can implement it with NANDs, or NORs


#### SR Latch circuit

- > When A closes ('1'), Out coil gets energy ('1')
- Also, Out contact closes, so, even if A opens ('0'), the "OR" keeps the Out coil powered ('1')
- Until the NC B contacts closes ('0'). Then the Out coil becomes '0'






### Latch with NOR




We also have the negate available for free!

s	R	Q	
0	0	LATCH	Memory
0	1	0	Reset
1	0	1	Set
1	1	-	Not legal






## Latch with NAND



s	R	Q
0	0	-
0	1	0
1	0	1
1	1	LATCH



Functional Block Diagrams




### **Function blocks**

Enable us grouping a functionality in a reusable elements

- > "aka": function ©
- > Multiple inputs, multiple outputs
- > Standard-defined functions vs. user-defined functions

IEC 61131-3 defines them graphically as






### Standard blocks: CTU

#### Up counter CTU

- > Gives output **Q** when *input pulse* **CU** reaches the *set value* **PV**
- > Reset input R
- Also, every time Q is set, CV is incremented








### Standard blocks: TON

#### Timer ON TON

- > Output **Q** has a rising edge when internal timer has value "time to pass" **PT**
- > Starts when **IN** has a rising edge, resets when **IN** has a falling edge
- > Also, *Elapsed Time* **ET** keeps trace of time







## Defining our own Function Blocks

- > Here, written in ST
- > Define function to reuse code
- > Define in, out, internal vars



```
FUNCTION BLOCK MyFb
VAR INPUT (* Inputs *)
 (* ... *)
END VAR;
VAR OUTPUT (* Outputs *)
 (* ... *)
END VAR;
VAR (* Internal *)
(* ... *)
END;
(* Instructions here *)
END FUNCTION BLOCK;
```



### References



#### Course website

http://hipert.unimore.it/people/paolob/pub/Industrial\_Informatics/index.html

#### My contacts

- > paolo.burgio@unimore.it
- http://hipert.mat.unimore.it/people/paolob/

#### Resources

- > W. Bolton, "Programmable Logic Controllers", 6th edition, Newnes
- "Industrial informatics" course by Proff. Vezzani and Pazzi @UNIMORE
- A "small blog"
  - http://www.google.com