Touch Lcd

Uploade screen firmware to screen

Step 1: Format the TF card and copy files

First ,the TF card is limited to max of 16GB.

Then run windows command system as administrator, then enter:

format g:/fs:fat32/a:4096/q

Note: g is the disk number of your TF card.

Unzip your download zip file and copy DWIN_SET folder to your TF card.

Step 2: Flash the firmware

Insert the TF card into the card socket (left slot at back side of the screen) ,and then power on the screen.

You can also insert it when the power is on. Wait for the blue screen to appear and the first line of the

screen "SD Card Process... END!" will show up when it's done. It may take 1-2 minutes. Take the TF card out

of slot ,just push the card lightly and it will pop up. Turn off the power and re-power on. Wait for the boot

screen, it may take 1-5s.

NOTE: In Europe TF card called Micro SD