


HOW TO

Link camera to Ax Pro on Hik-Connect app



Introduction:


Linking camera could record the video when alarm is triggered on AX Pro, this guide would introduce how to link camera to AX Pro and show how to view the event video on Hik-Connect app.

Add Camera


The requirement of camera are as below:

- The Video Encoding of Sub- Stream should be H.264
- IP camera should be in the same LAN with AX Pro device.

Note: AX Pro only get sub stream of IP camera.



- Login Hik-Connect app, tap the **device name** to enter page.
- Tap  to enter Settings options .
- Tap **Network Camera > Network Camera Channel > Add Channel**




- Enter IP Address, User name, Password of IP camera which you want to link, enable **Video Verification Report**, tap **OK** to finish adding camera.

Link Camera


Here we take Zone 2 as an example.:

- 1) Back to AX Pro page > **Device**, choose **Zone**,
- 2) Tap **Setting** of Zone 2 > **Link Camera**.
- 3) Choose the **Available Camera** and tap to **Link Zone 2**.




Trigger Alarm and receive event video

Login AX pro on web browser using Hik-Connect account and password.



Configure the **pre-record** and **post-record** of the linked camera: Pre-record 5s and Post-record 2s.Or Pre-record 2s and Post-record 5s.



Tap **Arm** button to arm device, when the event is triggered on Ax Pro, you will receive the event information in the **Notification** page on Hik-Connect app.

Tap event information to check details and tap **Playback** to play record video.

