
Install the driver

- 1. Plug the device in USB port. Now it requires you to install the driver
- 2. Click the install.exe



- 3. Click **NEXT**
- 4. Save INF file
- 5. Click **Install Now...** button (permit the install if anti-virus software popes up)

