AIRBUS A320/A321 - NORMAL CHECKLIST



PRE FLIGHT FLOWS

Download charts & NOTAMS Check weather & forecasts Load PAX, CARGO & FUEL

>> START SKYTRACK <<

PRE START CHECKLIST

PARKING BRAKE	SET
CHOCKS	REMOVED
GPU	CONNECTED
THROTTLETH	RUST LEVERS IDLE
ENGINE MASTERS	
BATTERIES	ON
GENERATOR SWITCHES	ON
EXT POWER	
ADIRS	
PANEL DISPLAYS	.BRIGHTNESS SET
NAV LIGHTS	
PANEL LIGHTS	ON if required
LANDING GEAR LEVER	CHECK DOWN
FLAPS	UP
SPOILER	
FUEL QUANTITY	
FASTEN SEAT BELTS	ON
NO SMOKING SIGNS	
Check Weather (ATIS, Fligh	t Services)
DE-ICE	TEST / CHECK
Request Clearanc	е
TRANSPONDER	
BEACON LIGHTS	ON
EMERGENCY LIGHTS	ARM
FMC	SETUP, CHECK
DEPARTURE BRIEFING	COMPLETE
DOORSCLOSED (CI	

STARTUP CHECKLIST

APU	START
APU BLEED	. RUN (WHEN AVAILABLE)
APU GEN	
Request Pushback –	Initiate Pushback
THRUST LEVERS	IDLE
ENGINE AREA	CLEAR
FUEL PUMP SWITCHES	ON
MODE SELECTOR	IGN / START
LEFT ENGINE	(ENG 1)
ENGINE MASTER 1	
AT N2 > 20% FUEL FLOW	
N1 INCREASING AS N2 INCR.	CHECK
OIL PRESSURE	
GENERATOR SWITCH	ON
REPEAT FOR RIGHT ENGINE	(ENG2)
FUEL FLOW	
HYDRAULIC PUMP SWITCHE	SON
APU	OFF
MODE SELECTOR	NORM

BEFORE TAXI CHECKLIST

PROBE/WINDOW HEAT	AUTO
HDG INDICATOR / ALTIMITERS	SET
STDBY INSTRUMENTS	SET
RADIOS AND AVIONICS	SET FOR DEPARTURE
AUTOPILOT	SET, don't activate
F/D	ON
AUTOBRAKE	MAX
ELEVATOR TRIM	SET FOR TAKE-OFF
FLIGHT CONTROLS	FREE AND CORRECT
Request Taxi Clearance	

TAXI CHECKLIST

TAXI LIGHTS	ON
PARKING BRAKE	
TAXI to assigned runway	SPEED Max. 20 knots
BRKS/GYRÖ/TURN COORDIN	
T/O CONFIG	DEPRESS / CHECK
T/O MEMO	GREEN

BEFORE TAKE-OFF CHECKLIST

PARKING BRAKE	SET
FLIGHT INSTRUMENTS	CHECK
ENGINE INSTRUMENTS	CHECK
TAKE-OFF DATA	(V1, VR, V2) CHECK
NAV EQUIPMENT	
LANDING LIGHTS	ON
STROBE LIGHT	ON
PITOT HEAT	AUTO
DE-ICE	AS REQUIRED
TRANSPONDER	TA/RA
Request Takeoff Clearance	

TAKE-OFF CHECKLIST

Smoothly increase thrus	st to 40% N1 let spool up
TAKEOFF THRUST	FULL OR TO/GA
	RELEASE
AT 100 KTS	SPEED CROSSCHECK
AT V1	COMMITED / GO (Decision)
AT Vr	ROTATE
PITCHslowl	y to 10deg, increase to 15deg
POSITIVE RATE OF CLIMB .	GEAR UP
PASSING F SPEED (PFD)	FLAPS 0
SPOILERS	DISARM
LANDING LIGHTS	AS REQUIRED

CLIMB-OUT CHECKLIST

THRUST LEVERS	CLB DETENT	
AP1	ENGAGE (when suitable)	
TAXI LIGHTS	OFF	
At TA (Transition-Altitude)		
ALTIMETERPUL	L TO SET STD (29.92 / 1013)	
	MAX. 250 KIAS	
	AS REQUIRED	
Passing 10'000 ft		
LANDING LIGHTS	OFF	
Above 1	10'000 ft	
FASTEN SEAT BELTS	OFF	



CRUISE CHECKLIST

Appalamenta to Crusian Con		
Accelerate to Cruise Spe		
ENGINE & INSTRUMENTS		
FUEL QUANTITY		
RADIOS		
AUTOPILOT	CHECK & SET	
LIGHTS		
ATIS / AIRPORT INFORMATION	CHECK	
ALTIMETER	CHECK	
RADIOS	SET	
DE-ICE	AS REQUIRED	
TODSET	TCAS TO BELOW	
Descent Speed		
FL240	0.76 MACH	
FL180		
At TA (Transition-Altitude)		
ALTIMETERR		
FL120		
Below 10'000 ft		
SPEED	250 KIAS	
LANDING LIGHTS		
LS		
FUEL QUANTITIES & BALANCE		
FLAPS / LANDING GEAR		
Check Weather (ATIS, Flight S		

APPROACH CHECKLIST

ALL INCACIT CITEOTICIO		
FASTEN SEAT BELTS		
RADIOS		
SPEED:	ESTABLISH 210 KIAS	
LANDING LIGHTS	CHECK ON	
TAXI LIGHTS	ON	
GND SPOILERS	ARM	
AUTO BRAKE	SET	
FLAPS		
SPEED:	ESTABLISH 180 KIAS	
AT 6 DME		
SPEED:		
LANDING GEAR		
LANDING GEAR 3 GREEN		
FLAPS	FULL	
Final Glideslope Descent :		
SPEED:		
PARKING BRAKE	VERIFY OFF	
DF-ICF	AS REQUIRED	

LANDING CHECKLIST

LANDING GEAR	CHECK DOWN
AUTOPILOT	AS REQUIRED
GO-AROUND ALTUTUDE	SET IN FCU
AUTO-THRUST	AS REQUIRED
LANDING MEMO	NO BLUE
LANDING SPEED	MANAGED
AFTER TOUCH DOWN	REVERSE THRUS
	VERIFY EXTENDED
BRAKES	AS REQUIREDT
AT 60 KIAS	CANCEL REVERSE THRUST

AFTER LANDING CHECKLIST

SPOLERS	DISARMED
FLAPS	RETRACT
ENG MODE SELECTOR	NORM
LANDING LIGHTS	OFF
STROBE LIGHTS	OFF
ANTI ICE	AS REQUIRED
APU	START
BRAKE TEMP	CHECK
TRANSPONDER	
Taxi to Assigned Gate/Parl	king (Speed Max 20 knots)
APU	START / CHECK RÚN
APU	GEN ON / CHECK VOLTS
ELEVATOR TRIM	TAKEOFF SETTING
turning into	the Gate:
TAXI LIGHTS	OFF

PARKING / SHUTDOWN CHECKLIST

PARKING BRAKES	SET
THRUST LEVERS	IDLE
GROUND CONTACT	ESTABLISH
GROUND OPERATIONS	AS REQUIRED (FMC2)
ELECTRICAL POWER	
ENGINE MASTER 1 & 2	OFF
PARKING BRAKES	
NAV LIGHTS	
EXTERIOR LIGHTS	
ANTI ICE	
PASSENGER SIGNS	OFF
DOORS	OPEN
FLIGHT DIRECTOR	OFF
APU BLEED	
FUEL PUMPS	
BEACON	
ECAM STS	DEPRESS
PANEL LIGHTS	OFF
ADIRS	
AVIONICS	
NO SMOKING	
APU	
BATTERIES	

>> SKYTRACK - PIREP FILED! <<