

2005 Nissan 350Z VQ35DE — Arnès motor / Engine harness print pack

Motor-control loom on the bench (F-series) · ECM MEC61-510 · 2 páginas: EC-123 + fichas

Card · color = contorno · 5V ámbar / 12V rojo / GND verde · Invertida L/R · FSM EC 2005 · OEM · not a service manual

1 · EC-123 INVERTIDA — MEC61-510 · (misma hoja que la portada)

nº pin arriba · código abajo · borde = cable · rojo = bancada · Invertida L/R



Motor rails · BATT 121=R/W · IGN 119=R/W 120=P · GND 1=B 115=B/W 116=B/R · KNK 15 · CKP 13 · CAN 86/94 · coils/inj · AFh 2/24

6-81

PATH 5V motor · ETC throttle (DBW) · 5V=47 · SNS TPS→66

ETC throttle

DBW · 5V=47 · motor ± · TPS

→47
W/R→4
L/B
M-→5
L/Y
M+SNS
B
GND→69
Y
TZ→50
G
T1

PATH A/F + HO2S · sensores → E12■F3 (heaters / poder) → ECM · heaters ECM 2 / 24

A/F Sens 1 B1

FSM · pass/RH · Inv

→16
LG/Bfuse
12V→35
L/W

1

3

5

→75
P/B→2
GY/R→56
W/L

2

4

6

A/F Sens 1 B2

FSM · driver/LH · Inv

→76
LGfuse
12V→55
L/B

1

3

5

→77
P→24
G/Y→58
W

2

4

6

HO2S2 B1

post-cat RH

fuse
12V→25
PIB

12V

htr

HO2S2 B2

post-cat LH

fuse
12V→6
PIL

12V

htr

A/F heaters / coil-inj 12V rail: E12■F3 (mate en joints abajo)

PATH Knock · sensor → F14/F229 → ECM 15 / GND 116 · otros sensores motor (directo → ECM)

Knock

→F14

→116
B→15
W

GND

15S

F14

FSM H.S. · GND

→15
W→116
B

15S

GND

F229

FSM H.S. · GND

→15
W→116
B

15S

GND

MAF

→ECM 51

→51
ORgnd
B

51S

GND

pwr
R

12V

CKP POS

→ECM 13

gnd
B

GND

→13
W/L

13S

12V
R/W

PWR

CMP B1

cam RH

gnd
B

GND

→33
R

33S

CMP B2

cam LH

gnd
B

GND

→14
R/L

14S

ECT

coolant

SNS
B

GND

→73
BR/Y

73S

IAT

intake air

SNS
B

GND

→34
Y/G

34S

VTC B1

intake cam RH · →ECM 11

ign
R

12V

→11
P

ECM

VTC B2

intake cam LH · →ECM 10

ign
R

12V

→10
W/G

ECM

Coil 1

→ECM 62

ign
R

12V

→62
Y/R

ECM

Coil 2

→ECM 81

ign
R

12V

→81
G/B

ECM

Coil 3

→ECM 61

ign
R

12V

→61
L/R

ECM

Coil 4

→ECM 80

ign
R

12V

→80
G/Y

ECM

Coil 5

→ECM 60

ign
R

12V

→60
P/UW

ECM

Coil 6

→ECM 79

ign
R

12V

→79
G/YR

ECM

Inj 1

→ECM 23

ign
R

12V

→23
R/B

ECM

Inj 2

→ECM 42

ign
R

12V

→42
B/R

ECM

Inj 3

→ECM 22

ign
R

12V

→22
R/Y

ECM

Inj 4

→ECM 41

ign
R

12V

→41
W/B

ECM

Inj 5

→ECM 21

ign
R

12V

→21
S/B

ECM

Inj 6

→ECM 40

ign
R

12V

→40
L/G

ECM

Joints motor · F103/gnd4 → E17 · Ign condenser · SNS GND · E12■F3 · E10■F1 (battery tray)

F103 gnd4

1/115/116 → E17

E17
B

D

→116
B/R

C

→115
B/W

B

→1
B

A

E17 body

ign

gnd

Ign condenser

noise · near cyl3

cyl3

→2µF

SNS GND

sensor grounds

→78
B

78

→67
B

67

→66
B

66

E12

8-pin GY · VB 119/120 · IGN

nc
R/W

12V

nc
—

2

JB-15A
R/B

12V

→120
P

12V

E7-17
W/L

12V

E17
B

GND

→119
R/W

12V

nc
—

8

F3

8-pin GY · VB 119/120 · IGN

nc
R/W

12V

nc
—

2

JB-15A
R/B

12V

→120
P

12V

E7-17
W/L

12V

E17
B

GND

→119
R/W

12V

nc
—

8

E10

9-pin GY · START · REV Y/R

E4-3
B/Y

12V

E7-26
Y/R

12V

JB-15A
R/B

12V

nc
—

4

→49
B

5V

nc
—

6

nc
—

7

→67
B/W

GND

→70
G/R

70S

F1

9-pin GY · START · REV Y/R

E4-3
B/Y

12V

nc
Y/R

12V

JB-15A
R/B

12V

nc
—

4

→49
B

5V

nc
—

6

nc
—

7

→67
B/W

GND

→70
G/R

70S