Wiring z80_dongle

Sense/ PullUp	Mega Name	Mega Pin	Z80 Pin	Z80 Name	Z80 Status			Z80 Status	Z80 Name	Z80 Pin	Mega Pin	Mega Name	Sense/ PullUp
	РС3	34	1	A11	Adr	Out T	Out T	Adr	A10	40	35	PC2	
	PC4	33	2	A12	Adr	Out T	Out T	Adr	A9	39	36	PC1	
	PC5	32	3	A13	Adr	Out T	Out T	Adr	A8	38	37	PC0	
	PC6	31	4	A14	Adr	Out T	Out T	Adr	A7	37	29	PA7	
	PC7	30	5	A15	Adr	Out T	Out T	Adr	A6	36	28	PA6	
PU	PB4	10	6	Clk	Clk	In	Out T	Adr	A5	35	27	PA5	
	PL4	45	7	D4	Data	Bidi T	Out T	Adr	A4	34	26	PA4	
	PL3	46	8	D3	Data	Bidi T	Out T	Adr	А3	33	25	PA3	
	PL5	44	9	D5	Data	Bidi T	Out T	Adr	A2	32	24	PA2	
	PL6	43	10	D6	Data	Bidi T	Out T	Adr	A1	31	23	PA1	
	+5V	+5V	11	+5V	Power	Power	Out T	Adr	A0	30	22	PA0	A15
	PL2	47	12	D2	Data	Bidi T	Power	Power	GND	29	GND	GND	
	PL7	42	13	D7	Data	Bidi T	Out	Ctrl	/REFSH	28	A14	PK6	
A8	PL0	49	14	D0	Data	Bidi T	Out	Ctrl	/M1	27	A13	PK5	
	PL1	48	15	D1	Data	Bidi T	In	Ctrl	/RESET	26	40	PG1	PU
PU	PG0	41	16	/INT	Ctrl	In	In	Ctrl	/BUSRQ	25	17	PH0	PU
PU	PG5	4	17	/NMI	Ctrl	In	In	Ctrl	/WAIT	24	39	PG2	PU
	PK3	A11	18	/HALT	Ctrl	Out	Out	Ctrl	/BUSAK	23	A12	PK4	
	PK1	А9	19	/MREQ	Ctrl	Out T	Out T	Ctrl	/WR	22	18	PD3	
	PK2	A10	20	/IORQ	Ctrl	Out T	Out T	Ctrl	/RD	21	19	PD2	