| Model Date | | | $\neg \vdash$ | | | 1 | Maple HUB | | | | | | | | Maple LTE | | | | | | | | | Maple Sensor | | | | | | | | | | | | \neg | | | | |
|------------|----------------|---------------|---------------|--------------|-------------|------------|-----------|-----------------|-------|--------------|-----------|---------------------------|-----------|------------|--|------------------|---------|--------------|-------------------------|-----------|-----------|----------|----------------|------------------|-------------|----------------|------------------------------|----------------------------|---------------------------------|--------------------|---------|------------|-----------------|--------|--------------|--|-----|-----|-------------|------|
| | Maple HUB SN S | Maple I | Maple LTI | Testing Seve | Ontrovelle | FW Perform | FW (MI | W fter Motic | Alarm | detection | LTE | AC power to Battery power | | Attach the | Hub | FW (Parform | FW (May | % Rathery | LTE to WiFi WiFi to LTE | LTE B | ox LTE | AC power | to Battery pow | er On boardir | FW / Refere | FW | % | Con | tact sensor | Temperature sensor | | | Alarm detection | | Decreased | sed Increased Accelerometer Water leak T | | | impe Mot | |
| | | | | | | Onboardi | upgrade) |) upgrad | ie) | Smoke (T3) C | r3) co (1 | charging | switching | switching | hing Box (by LTE) upgrade) upgrade) switching sw | switching switch | ing SOC | SOC charging | switching | switching | . Contact | upgrade | upgrade) | Battery | Move av | vay Move close | Check Temperature Room | High temperature detection | Low temperature detection | Smoke (T3) | CO (T4) | brightness | brightness | (Drop) | letection bu | eton | | | | |
| SH1001 | 19/12/2022 | AB51277PD009D | NA | NA | my.arlo.com | NG | NA | NA | NA. | . NA | NA. | NA. | NA | NA | NA. | NA | NA. | NA. | NA. | NA NA | NA. | . NA | NA | NA | V | NA | NA | NA | NA. | NA. | NA. | NA. | NA. | NA. | NA | NA | NA. | NA. | NA I | NA N |