2026 VW Service

1 Maintenance Schedules

⇒Maintenance Schedule (Gas Vehicles)

⇒Maintenance Schedule (Battery Electric Vehicles)

1.1 Maintenance Schedule (Gas Vehicles)

Note

The intervals shown in this table are based on vehicles operating under normal conditions. In case of severe conditions, such as extremely low temperatures, excessive dust, etc., it is necessary for certain operations to be carried out in between the given intervals. This applies particularly to engine oil changes, Drivetrain fluid service , and the cleaning or replacing of the air cleaner filter element.

Service Intervals										
— Miles	**10K**	**20K**	**30K**	**40K**	**50K**	**60K**	**70K**	**80K**	**90K**	**100K**
— Kilometers	**15K**	**30K**	**45K**	**60K**	**75K**	**90K**	**105K**	**120K**	**135K**	**150K**
⇒Minor Maintenance 1)	X		X		X		X		X	
⇒Standard Maintenance 2)		X		X		X		X		X
⇒Extended Maintenance				X				X		
⇒Additional Maintenance Items										
1) First minor maintenance service at 10,000 miles (15,000 km) or 1 year after delivery, whichever occurs first. Minor maintenance services thereafter occur at intervals of 20,000 miles (30,000 km) or every 2 years after the last minor maintenance service, whichever occurs first. 2) Standard maintenance services occur at intervals of 20,000 miles (30,000 km) or every 2 years, whichever occurs first. 3) Extended maintenance services occur at intervals of 40,000 miles (65,000 km). Only applies in combination with Standard Maintenance.										

✓ all completed items

1.1.1 Minor Maintenance

Service Item	Applicability
☐ Engine Oil, Change and Replace Oil Filter	All Vehicles
☐ Front and Rear Brake Pad Thickness and Brake Rotor Condition, Check	All Vehicles
☐ Service Interval Display, Reset	All Vehicles
☐ Tires – Rotate front to rear (Canada Only)	All Vehicles
☐ See ⇒Additional Maintenance Items	All Vehicles

1.1.2 Standard Maintenance

Service Item	Applicability
☐ Perform Minor Maintenance	All Vehicles
☐ Automatic Headlamp Control, Check Function	All Vehicles
☐ Battery and Auxiliary Battery, Check with Battery Tester if Necessary	All Vehicles
☐ Brake Fluid Level, Check Depending on Brake Pad Wear	All Vehicles
☐ Brake System and Shock Absorbers, Inspect for Leaks and Damage.	All Vehicles
☐ Cooling System, Check Freeze Protection and Coolant Level	All Vehicles
☐ Engine and Components in Engine Compartment (from Below), Inspect for Leaks and Damage	All Vehicles
☐ Engine and Engine Compartment Components (from Above), Inspect for Leaks and Damage	All Vehicles
☐ Engine Oil Level, Check	All Vehicles
☐ Front and Rear Brake Pad Thickness and Brake Rotor Condition, Check	All Vehicles
☐ Front Lighting, Check Function	All Vehicles
☐ Headlamp Washer System, Check Function	All Vehicles
☐ Headlamps, Check and Adjust if Necessary	All Vehicles
☐ Horn, Check Function	All Vehicles
☐ Rear Lamps, Check Function	All Vehicles
☐ Removable Trailer Hitch, Check (if equipped).	All Applicable Vehicles
☐ Road Test, Perform	All Vehicles
☐ Service Interval Display, Reset	All Vehicles
☐ Stationary Cornering Lamp, Check Function	All Vehicles
☐ Tire Pressure Monitoring System, Calibrating to Tire Pressure Adjustment	All Applicable Vehicles
☐ Tire Pressure, Check	All Vehicles
☐ Tires – Rotate front to rear – Canada Only	All Vehicles
☐ Tire Repair Kit, Check for Damage and Use	All Applicable Vehicles
☐ Tires, Check Condition and Wear Pattern. Tread Depth, Enter	All Vehicles
☐ Torque splitter: Read out oil deterioration using the Vehicle Diagnostic Tester (if equipped)	All Applicable Vehicles
☐ Transmission, Final Drive and CV Boots, Check for Leaks and Damage	All Vehicles
☐ Windshield Wiper/Washer System, Check Freeze Protection and Filling Fluid	All Vehicles
☐ Windshield Wiper/Washer System, Check Function and for Damage, Adjust if Necessary	All Vehicles
☐ Wiper Blades, Check for Damage and Check Park Position	All Vehicles
☐ See ⇒Additional Maintenance Items	All Vehicles

1.1.3 Extended Maintenance

Service Item	Applicability
☐ Ball Joints, Axle Bearings, Coupling Rod and Stabilizer Bar Bushings, Inspect for Damage	All Vehicles
☐ Body Interior and Exterior, Inspect for Corrosion	All Vehicles
☐ Exhaust System, Inspect for Leaks, Attachment and Damage	All Vehicles
☐ Front and Rear Coil Springs and Stop Buffers, Inspect for Damage	All Vehicles
☐ Interior Lamps in Headliner, Luggage Compartment and Glove Compartment Lamps, Check Function	All Vehicles
☐ Ribbed Belt, Check Condition	All Vehicles
☐ Sliding Sunroof, Perform noise and Function Test. Clean and lubricate if needed	All Applicable Vehicles
☐ Underbody, Inspect Underbody Protection, Trim Panels, Wire Routing and Plugs for Damage	All Vehicles
☐ Windshield, Inspect for Damage	All Vehicles
☐ See ⇒Additional Maintenance Items	All Vehicles

1.1.4 Additional Maintenance Items

Service Item	Interval	Applicability
☐ Air Filter - Replace and clean screen	Every 60,000 miles (90K km), or 6 years, whichever occurs first	All Vehicles
☐ AWD Clutch - Change fluid	Every 3 years	All Applicable Vehicles
☐ Brake and Clutch System, Changing Brake Fluid	3 years aft. registration, then every 2 years -USA	All Vehicles
	2 years aft. registration, then every 2 years -Canada	
☐ Dust and Pollen Filter - Replace	Every 40,000 miles (60K km), or 2 years, whichever occurs first	All Vehicles
☐ Rear Axle Differential with Torque Vectoring - Change fluid (if applicable)	Every 40,000 miles (60K km), or 4 years, whichever occurs first	Golf R
☐ Front Axle Differential Lock - Change fluid	Every 3 years	All Applicable Vehicles
☐ Sunroof Drains - Check for blockage, clean if necessary	Every 20,000 miles (30K km), or 2 years, whichever occurs first	Atlas
		GTI / Golf R
		Tiguan (RM1)
		Taos
		Jetta

Service Item	Interval	Applicability
☐ Spark Plugs - Replace	Every 40,000 miles (60K km), or 6 years, whichever occurs first	Golf R
	Every 80,000 miles (120K km), or 6 years, whichever occurs first	Atlas Atlas Cross Sport, Jetta GLI GTI Taos, Tiguan (RM1)
☐ Transmission, Automatic - Change Fluid & filter (if applicable) » USA Only«	Every 80,000 miles (120K km)	09H: Atlas, Atlas Cross Sport, Tiguan (RM1)
		0GC (DSG): GTI, Golf R, Jetta
☐ Transmission, Automatic - Change Fluid & filter (if applicable)	Every 60,000 miles (90K km) - If driven under Severe Operation (i.e. taxi/ towing, etc.)	09U: Jetta, Taos, Tiguan (RM1)
☐ Ribbed belt starter generator and tensioning roller: replace	Every 110,000 miles (180K km)	All applicable engines
☐ Toothed Belt, Camshaft Drive Tensioning Roller (Gas Engine) - Check	Every 180,000 miles (300 km), or 15 years	GTI, Golf R, Jetta, Taos, Tiguan (RM1)
☐ Coolant Pump Toothed Belt - Check	Every 180,000 miles (300K km), or 15 years	Engines W/ toothed belts
☐ Tire Filler Bottle in tire mobility set - Replace	Every 4 years regardless of mileage driven	All applicable vehicles

1.2 Maintenance Schedule (Battery Electric Vehicles)

Note

The intervals shown in this table are based on vehicles operating under normal conditions. In case of severe conditions, such as extremely low temperatures, excessive dust, etc., it is necessary for certain operations to be carried out in between the given intervals.

Service Intervals										
— Miles	**10K**	**20K**	**30K**	**40K**	**50K**	**60K**	**70K**	**80K**	**90K**	**100K**
— Kilometers	**15K**	**30K**	**45K**	**60K**	**75K**	**90K**	**105K**	**120K**	**135K**	**150K**
⇒Standard Maintenance - small [1)]	X		X		X		X		X	
⇒Standard Maintenance [2)]		X		X		X		X		X
⇒Additional Maintenance Items										

Service Intervals
1) First standard maintenance-small service at 10,000 miles (15,000 km) or 1 year after delivery, whichever occurs first. Standard maintenance-small services thereafter occur at intervals of 20,000 miles (30,000 km) or every 2 years after the last standard maintenance-small service, whichever occurs first.
2) Standard maintenance services occur at intervals of 20,000 miles (30,000 km) or every 2 years, whichever occurs first.

✓ all completed items

1.2.1 Standard Maintenance - small

	Service Item	Vehicle Applicability
☐	Battery (12V) and High-Voltage Battery, Checking with Vehicle Diagnostic Tester	All Vehicles
☐	Use the Vehicle Diagnostic Tester to check for DTCs	All Vehicles
☐	Service Interval Display, Resetting	All Vehicles
☐	Tires, Checking Condition and Wear Pattern; Tread Depth, Entering	All Vehicles
☐	See ⇒Additional Maintenance Items	All Vehicles

1.2.2 Standard Maintenance

	Service Item	Vehicle Applicability
☐	Perform Minor Maintenance	All Vehicles
☐	Automatic Headlamp Control, Checking Function	All Vehicles
☐	Ball Joints, Axle Bearings, Coupling Rod and Stabilizer Bar Rubber Bushings, Inspect for Damage	All Vehicles
☐	Battery (12V) and High-Voltage Battery, Checking with Vehicle Diagnostic Tester	All Vehicles
☐	Body Interior and Exterior, Inspect for Corrosion	All Vehicles
☐	Brake Fluid Level, Checking Depending on Brake Pad Wear	All Vehicles
☐	Brake System and Shock Absorbers, Inspect for Leaks and Damage.	All Vehicles
☐	Charging Cable, Checking Presence and Condition.	BEV
☐	Cooling System, Checking Freeze Protection and Coolant Level	All Vehicles
☐	Engine and Components in Engine Compartment (from Below), Inspect for Leaks and Damage	All Vehicles
☐	Engine and Engine Compartment Components (from Above), Inspect for Leaks and Damage	All Vehicles
☐	Front and Rear Brake Pad Thickness and Brake Rotor Condition, Check	All Vehicles
☐	Front and Rear Coil Springs and Stop Buffers, Inspect for Damage	All Vehicles
☐	Front Lighting, Checking Function	All Vehicles
☐	Guided Fault Finding - Use the Vehicle Diagnostic Tester to check for DTCs	BEV

3

Service Item		Vehicle Applicability
☐	Headlamp Washer System, Checking Function	All Vehicles
☐	Headlamps, Checking and Adjusting if Necessary	All Vehicles
☐	High-Voltage Battery Charge Level, Checking and Charging if Necessary.	BEV
☐	High-Voltage Battery, Charging.	BEV
☐	High-Voltage Charging Sockets in Radiator Grille or Fuel Filler Cap. Visual Inspection Contamination and Damage, Performing.	BEV
☐	High-Voltage Components and High-Voltage Cables, Inspect for Damage, Correct Wire Routing and Attachment.	BEV
☐	Horn, Checking Function	All Vehicles
☐	Interior Lamps in Headliner, Luggage Compartment and Glove Compartment Lamps, Checking Function	All Vehicles
☐	Rear Lamps, Checking Function	All Vehicles
☐	Removable Trailer Hitch, Checking. if equipped	All Vehicles
☐	Road Test, Performing	All Vehicles
☐	Service Interval Display, Resetting	All Vehicles
☐	Stationary Cornering Lamp, Checking Function	All Vehicles
☐	Tie Rods, Checking Play, Attachment and Ball Joint Boots	All Vehicles
☐	Tire Pressure Monitoring System, Calibrating to Tire Pressure Adjustment	All Vehicles
☐	Tire Pressure, Checking	All Vehicles
☐	Tire Repair Kit, Checking for Damage and Use	All Vehicles
☐	Tires, Checking Condition and Wear Pattern; Tread Depth, Entering	All Vehicles
☐	Transmission, Final Drive and CV Boots, Checking for Leaks and Damage	All Vehicles
☐	Underbody, Inspect Underbody Protection, Underbody Trim Panels, Wire Routing and Plugs for Damage	All Vehicles
☐	Warning Label, Checking Presence.	BEV
☐	Windshield Wiper/Washer System, Checking Function, Spray Nozzle Adjustment and for Damage, and Adjusting if Necessary	All Vehicles
☐	Windshield, Inspect for Damage	All Vehicles
☐	Wiper Blades, Bringing into Service Position, Checking for Damage and Checking Park Position	All Vehicles
☐	See ⇒Additional Maintenance Items	All Vehicles

1.2.3 Additional Maintenance Items

Labor Item	Interval	Vehicle Applicability
☐ Brake Fluid - Change	3 years after registration and then every 2 years, regardless of mileage **(Only USA)** 2 years after registration and then every 2 years, regardless of mileage **(Only Canada)**	All Vehicles
☐ Dust and Pollen Filter - Replace	Every 2 years	All Vehicles

© 2.2026 Volkswagen Group of America, Inc.
All rights reserved. Information contained in this document is based on the latest information available at the time of printing and is subject to the copyright and other intellectual property rights of Volkswagen Group of America, Inc., its affiliated companies and its licensors. All rights are reserved to make changes at any time without notice. No part of this document may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, nor may these materials be modified or reposted to other sites, without the prior expressed written permission of the publisher.