


HEAT SET INSERTS

This design relies heavily on heat set inserts. Make sure you got the proper inserts (check the hardware reference for a close up picture).

If you've never worked with heat set inserts before we recommend you watch a guide.



https://voron.link/cubk4lh




Cable Chain

REMOVE END LINK

Reattaching the chain later makes the assembly a lot easier.




We won't be showing the chain in later pictures.




M3x8 BHCS


A DRIVE WWW.VORONDESIGN.COM



A DRIVE

WWW.VORONDESIGN.COM







upside down.

A NOTE ON SHIMS


We specify shims as they have a consistent thickness compared to regular washers. If you sourced washers instead make sure to measure their thickness (target = 0.5mm) to avoid issues with the stackup.





XY JOINTS WWW.VORONDESIGN.COM



XY JOINTS WWW.VORONDESIGN.COM









UPSIDE DOWN ASSEMBLY

For ease of assembly we recommend to assemble the XY joints upside down.


X CARRIAGE WWW.VORONDESIGN.COM








DON'T TIGHTEN

Leave the nuts loose. The belt is threaded into this part in the next step.











A lubrication film is required to ensure smooth operation and longevity. Refer to the BOM for lubricant options.









CHECK ORIENTATION


The larger gear section must be on the right hand side. Check for any rubbing or binding.

ELECTRONICS & WIRING WWW.VORONDESIGN.COM











TOPHAT WWW.VORONDESIGN.COM





Heat Set Insert

