# DISCONNECT POWER CORD BEFORE SERVICING IMPORTANT - RECONNECT ALL GROUNDING DEVICES

All parts of this appliance capable of conducting electrical current are grounded. If grounding wires, screws, straps, clips, nuts or washers used to complete a path to ground are removed for service, they must be returned to their original position and properly fastened.

#### **ELECTRICAL SPECIFICATIONS**


Temperature Control (Position 5)	7-(-11 )°F
Defrost Control	
	w/ no door openings
Overtemperature Thermostat	140-110°F
Defrost Thermistor	75°F
Electrical Rating: 115V AC 60 Hz	11.6 Amp
Maximum Current Leakage	0.75 mA
Maximum Ground Path Resistance	

## **NO LOAD PERFORMANCE**

Control Position MID/MID and Ambient of: <u>70°F</u>	<u>90°F</u>
Fresh Food, °F34-40	34-40
Frozen Food, °F(-3) 3	(-3) 3
Run Time, %<80	=100

#### REFRIGERATION SYSTEM

Refrigerant Charge (R134a)	
Compressor	833 BTU/hr @
	3000 RPM
Minimum Compressor Capacity	22 inches
Minimum Equalized Pressure	
@ 70°F	40 PSIG
@ 90°F	54 PSIG




### IMPORTANT SAFETY NOTICE


This information is intended for use by individuals possessing adequate backgrounds of electrical, electronic and mechanical experience. Any attempt to repair a major appliance may result in personal injury and property damage. The manufacturer or seller cannot be responsible for the interpretation of this information, nor can it assume any liability in connection with its use.

#### INSTALLATION


Minimum clearance required for air circulation:	
TOP	1'
SIDES	0.125'
REAR	0.5'

#### **AIR FLOW**





Pub. No. 31-51678 1678X



Some components are only on applicable models. (See above schematic).