This is Google's cache of http://sdk.rethinkrobotics.com/intera/Gazebo Tutorial. It is a snapshot of the page as it appeared on Oct 5, 2019 08:04:29 GMT. The current page could have changed in the meantime. Learn more.

Full version Text-only version View source

Tip: To quickly find your search term on this page, press Ctrl+F or ℋ-F (Mac) and use the find bar.

Create accountLog in

Search Intera SDK Search

- More
 - View source
 - History
- Page

Gazebo Tutorial

- Installation & Configuration
 - o Robot Setup
 - Workstation Setup
 - Networking
 - o Hello Robot!
 - Hardware Components
 - o SDK Workstation Requirements
 - Robot Workspace Guidelines
 - Field Service Menu (FSM)
 - Time and NTP
 - SDK Software Update
 - SDK Release Notes
- Concepts
 - SDK Robot-Workstation Overview
 - E-STOP and Enable Robot
 - Arm Calibration
 - o Arm Control Systems
 - API Reference
- Tutorials
 - Interaction Control Tutorial
 - Motion Interface Tutorial
 - MoveIt! Tutorial
 - o Gazebo Tutorial
- Code Examples
 - Running Examples Overview
 - o Camera Image Display Example

 - Gripper Example
 Gripper Cuff Control Example
 - o Head Display Image Example
 - Head Movement Example
 - Lights Blinking Example
 - IK Service Example
 - Joint Position Example
 - Joint Position Waypoint Example
 - Joint Torque Springs Example
 - o Joint Trajectory Playback Example
 - o Set Interaction Options Example
 - o Motion Interface Go-To-Joint Angles
- Support
 - User Forum
- · Tools
 - o All Pages
 - o Print
 - <u>Upload File</u>
 - What Links Here?

Jump to: navigation, search

This tutorial describes how to use Sawyer with Gazebo the standard Physics Simulator for ROS.

Gazebo Logo

Please visit the Gazebo Tutorials homepage for more information about the Physics simulator

Contents

- 1 Installation/Prerequisites
- 2 Sawyer Simulator Installation

- o 2.1 Simulation
- 3 Smoke Test
- 4 Run SDK Examples
- 5 Troubleshooting

Installation/Prerequisites

- Make sure you have followed the Workstation Setup tutorial before beginning this section. Sawyer Gazebo is only available for Ubuntu 16.04, ROS Kinetic, and Gazebo 7.
- Ensure the following software packages are installed:
- ROS Kinetic
- \$ sudo apt-get install gazebo7 ros-kinetic-qt-build ros-kinetic-gazebo-ros-control ros-kinetic-gazebo-ros-pkgs ros-kinetic-ros-control ros-kinetic-control-to

Sawyer Simulator Installation

- ROS Kinetic
 - From your catkin workspace where the SDK resides, use wstool to install and update:

Install sawyer simulator

```
$ mkdir -p ~/ros_ws/src
$ cd ~/ros_ws/src
$ git clone https://github.com/RethinkRobotics/sawyer_simulator.git
$ cd ~/ros_ws/src
$ wstool init .
$ wstool merge sawyer_simulator/sawyer_simulator.rosinstall
$ wstool update
```

IMPORTANT: Make sure all simulator repositories update to their proper branch.

Build Source

```
$ source /opt/ros/kinetic/setup.bash
$ cd ~/ros_ws
$ catkin_make
```

Simulation

- The intera.sh shell has a special hook of *sim* for Simulation. Run the Intera shell script with sim specified:
- \$./intera.sh sim
 - Start simulation with controllers:
- \$ roslaunch sawyer_gazebo sawyer_world.launch

Smoke Test

Check if the simulator was installed and launched successfully by typing the following commands:

```
$ rosnode list
```

This should list the nodes as here.

```
$ rostopic list
```

This should list the topics as here.

\$ rostopic echo /robot/state

By default, the following messages should be displayed at 100 HZ.

```
enabled: False
stopped: False
error: False
estop_button: 0
estop_source: 0
```

Run SDK Examples

• Start Joint Torque Springs example:

```
$ ./intera.sh sim
$ roslaunch sawyer_gazebo sawyer_world.launch
*in a new terminal*
$ ./intera.sh sim
$ rosrun intera_examples joint_torque_springs.py
```

• Or, Start Simulated Pick and Place example:

\$./intera.sh sim
\$ roslaunch sawyer_sim_examples sawyer_pick_and_place_demo.launch

For additional information on the interfaces that are implemented with this release, visit the Simulator API page.

Troubleshooting

• Please refer to the troubleshooting page Gazebo Troubleshooting

Retrieved from "http://sdk.rethinkrobotics.com/intera/a/index.php?title=Gazebo Tutorial&oldid=1565" Powered by MediaWiki

- © 2019 Rethink Robotics. All rights reserved.
- Special page
- Privacy policy
 About Intera SDK
- Disclaimers