

INTEGRATION NOTE

Future Automation TV Lifter - Crestron Home Driver

Manufacturer:	Future Automation
Model(s):	Compatible RS-232 TV lifters/controllers
Device Type:	Extension Device - TV Lifter
Control Platform:	Crestron Home (4-Series processors, e.g. CP4-R)
Crestron Home Requirement:	Supported Crestron Home 4-Series system
Connection:	RS-232 serial COM port; default 9600 baud, 8N1
Driver Developer:	Home Ergonomic Programming
Document Revision Date:	11 July 2026

OVERVIEW

This driver allows a Crestron Home system to control compatible Future Automation TV lifters through a processor COM port, with commands available from the device page and Crestron Home sequences.

The driver uses the Future Automation RS-232 command set. It is send-only: commands are transmitted to the lifter, but position, movement and fault status are not reported back to Crestron Home.

SUPPORTED FEATURES

Lifter control:

- Move In
- Move Out (without swivel)
- Move Out to right limit
- Move Out to left limit
- Home (hinge down and swivel centre)
- Memory position A
- Memory position B
- Memory position C
- Memory position D
- Memory position E
- Memory position F
- Stop

ANY FEATURE NOT SPECIFICALLY NOTED AS SUPPORTED SHOULD BE ASSUMED TO BE UNSUPPORTED.

DRIVER LICENCE

This driver requires a licence key after the one-hour evaluation period. Licences are issued per controller: one licence covers all instances of the Future Automation driver on the same Crestron Home processor.

Licences can be purchased from <http://home-ergonomic-programming.co.uk>. Payment is processed securely by Polar, our merchant of record, and your licence key is emailed automatically when the purchase completes.

Enter the licence key when adding the driver, or later in Installer Settings. The driver activates automatically and binds the licence to the processor. Internet access is required for activation and periodic validation.

DEVICE SETUP

Install and commission the Future Automation lifter in accordance with the manufacturer's instructions before connecting it to the Crestron processor.

Connect the lifter's RS-232 control interface to an available COM port on the Crestron Home processor or supported Crestron serial interface. Confirm the correct TX, RX and ground wiring for the lifter model.

The driver defaults to 9600 baud, 8 data bits, no parity, 1 stop bit, RS-232 and no handshaking (8N1). Baud rate is installer-adjustable; confirm the required settings in the documentation supplied with the specific lifter/controller.

Each command is terminated with a carriage return. The driver does not require or process position feedback from the lifter.

INSTALLATION PROCESS

1. Copy the driver package (.pkg) file to the Crestron Home processor. Connect by SFTP using Crestron Toolbox, FileZilla or another suitable client, then copy the package to:

`/user/ThirdPartyDrivers/Import`

2. Crestron Home imports the driver automatically. This can take a few minutes; the package disappears from the Import directory after processing.

3. In the Crestron Home Setup app, add the Future Automation TV Lifter extension driver to the appropriate room and assign it to the required COM port.

4. Enter a descriptive Device Display Name, such as 'Living Room TV Lift', and enter the Polar licence key. The key can also be entered later during the evaluation period.

5. Confirm the baud rate and serial wiring, then test In, Out and Stop before testing swivel, Home and memory-position commands. Add the required commands to Crestron Home sequences or automations.

COMMON MISTAKES

- 1. TX and RX are crossed incorrectly, or signal ground is not connected.**
- 2. The selected COM port or serial mode does not match the physical connection.**
- 3. Baud rate or other serial settings do not match the Future Automation controller. The driver defaults to 9600 baud, 8N1, with no handshaking.**
- 4. Expecting status feedback. This is a send-only driver, so Crestron Home does not display the lifter's position, movement or faults.**
- 5. Licensing errors are commonly caused by missing internet or DNS access. Allow outbound HTTPS (TCP port 443) from the processor to api.polar.sh.**

SUPPORT

If you have an issue not covered here, contact support@home-ergonomic-programming.co.uk. Include the lifter/controller model, wiring details, configured serial settings and a recent processor error log.

DISCLAIMER

This driver is developed and supplied by Home Ergonomic Programming. It is an independent product: Home Ergonomic Programming is not affiliated with, endorsed by or connected to Future Automation.

Future Automation and its product names are trademarks of their respective owners.

By purchasing a licence for, installing or using this driver you agree to the Terms and Conditions at the end of this document. The driver is provided without warranty; always test it fully with the target lifter before live use.

TERMS AND CONDITIONS

These Terms and Conditions ("Terms") apply to the sale of licences for, and the supply and use of, the Future Automation TV Lifter Crestron Home driver. Please read them carefully before purchasing a licence or installing the software. If you do not agree to these Terms, do not purchase, install or use the software.

1. About us

- 1.1** The software is developed and supplied by Home Ergonomic Programming ("we", "us", "our").
- 1.2** You can contact us by email at HomeErgonomicProgramming@proton.me.

2. The software

- 2.1** These Terms apply to the Future Automation TV Lifter Crestron Home driver, together with any updates or new versions we may supply (the "Software").

2.2 The Software is licensed to you, not sold. All intellectual property rights in the Software remain our property at all times, including after installation on your equipment.

3. Licence

3.1 The Software requires a licence key to function. Licences are issued on a per-controller basis: a single licence covers all instances of the Software on the same control processor. The licence key is activated over the internet and locked to the first control processor on which it is used.

3.2 Subject to payment of the applicable licence fee, we grant you a non-exclusive, non-transferable, limited, revocable licence to install and use the Software on the control processor specified at the time of purchase. The number of installations must not exceed the number of licences you have purchased.

3.3 A licence is valid only for the specific control processor identified at the time of purchase and may not be resold or transferred to any other system. In exceptional circumstances we may, at our sole discretion, authorise the transfer of a licence to a new system, and we reserve the right to charge an administrative fee for this service or to refuse authorisation.

3.4 You may not copy (except as reasonably necessary for installation and backup), distribute, sell, sub-license, rent or lease the Software to any third party without our prior written consent.

3.5 You may not decrypt, decompile, disassemble, reverse engineer, translate, modify or create derivative works of the Software, in whole or in part. Any breach of this clause will immediately terminate all licences held by you.

3.6 Licence activation and periodic licence validation require the control processor to have internet access. We are not liable for any interruption to the operation of the Software caused by network restrictions, firewall rules or DNS failures at the installation site that prevent communication with the licensing service.

4. Ordering and payment

4.1 The Software is designed to be installed and configured by qualified system integrators for the Crestron Home platform. We sell business-to-business only and do not licence the Software to end consumers. By purchasing a licence you confirm your status as a qualified system integrator. If you are the owner of a system and believe you require the Software, please contact your system integrator, who can obtain a licence and carry out the integration work on your behalf.

4.2 Licences can be purchased from <http://home-ergonomic-programming.co.uk>. All purchases are processed by Polar (polar.sh), acting as merchant of record. Polar handles payment processing and the calculation, collection and remittance of any applicable VAT or sales taxes, and issues the receipt for your purchase. We do not see, handle or store your payment card details.

4.3 Prices are as displayed at checkout and are exclusive of any applicable taxes, which are calculated and added at checkout by the merchant of record. We reserve the right to amend prices, or to withdraw the Software from sale, at any time.

4.4 Please ensure the details you provide when ordering are complete and correct; we cannot be held responsible for any delays or losses caused by incorrect information being supplied. A contract between you and us for the licence of the Software exists once you have received your licence key.

5. Delivery

5.1 The Software is supplied by download only; it is not available in any physical format and there are no delivery charges. Licence keys are delivered automatically by email by the merchant of record on completion of purchase, to the address given at the time of ordering. Please check your spam folder before contacting us regarding a missing licence key.

6. Refunds

6.1 We do not generally offer refunds on licensing. If you have made a mistake during your purchase, or have another legitimate reason for requiring a refund, please contact us as soon as possible using the details in clause 1.2. A refund may be offered within 7 working days of purchase in some circumstances, but no refund will be considered once the Software has been installed on the relevant control processor. Refunds are processed by the merchant of record and may additionally be subject to its terms.

7. Third-party devices and services

7.1 The Software controls equipment provided by a third party. Future Automation and its product names are trademarks of their respective owners. We are not affiliated with, endorsed by or connected to Future Automation.

7.2 Operation of the Software depends on the connected Future Automation lifter/controller, its serial interface and the installation wiring. Hardware, firmware or protocol changes made by the manufacturer may affect functionality. We are not responsible for loss of functionality caused by such changes, although we will use reasonable endeavours to restore compatibility where practicable.

7.3 We reserve the right to modify, suspend or withdraw the Software at any time and for any reason, including where the equipment or service it controls is discontinued or substantially modified.

8. Warranty disclaimer

8.1 The Software is provided “as is” and “as available”, without any warranty, condition or representation of any kind, whether express or implied, to the maximum extent permitted by law, including without limitation any implied warranties of satisfactory quality, fitness for a particular purpose and non-infringement.

8.2 We do not warrant that the Software will meet your requirements, that its operation will be uninterrupted, timely, secure or error-free, or that any defects will be corrected.

8.3 Whilst every care is taken in the development and testing of the Software, you must always carry out your own testing in the target system before first use. You are solely responsible for verifying the Software's suitability for your project.

9. Limitation of liability

9.1 Nothing in these Terms excludes or limits our liability for death or personal injury caused by our negligence, for fraud or fraudulent misrepresentation, or for any other liability that cannot be excluded or limited under English law.

9.2 Subject to clause 9.1, we shall not be liable, whether in contract, tort (including negligence) or otherwise, for any indirect or consequential loss, loss of profit, loss of business, loss of data, or damage to computer systems or control platforms, arising out of or in connection with the installation or use of the Software.

9.3 Subject to clause 9.1, our total aggregate liability arising out of or in connection with the Software shall not exceed the amount paid by you for the licence to the Software or £100, whichever is the greater.

9.4 You install and use the Software at your own discretion and risk.

10. Support and updates

10.1 Support for the Software is provided on a reasonable-endeavours basis via the contact details in clause 1.2. When requesting support, please include as much detail as possible, including a recent processor error log.

10.2 The Software is supported for as long as it is offered for sale. We reserve the right to withdraw the Software from sale and discontinue on-going support at any time and for any reason; the remainder of your rights and obligations under these Terms will not be affected.

10.3 We may release updates to the Software from time to time, but we are under no obligation to do so.

11. Termination

11.1 The licence granted under these Terms terminates automatically if you breach any of them. On termination you must remove the Software from all control processors and destroy all copies in your possession.

12. General

12.1 These Terms constitute the entire agreement between you and us in relation to the Software.

12.2 Each of the paragraphs of these Terms operates separately. If any court or relevant authority decides that any of them is unlawful or unenforceable, the remaining paragraphs will remain in full force and effect.

12.3 This agreement is between you and us. No other person shall have any right to enforce any of these Terms.

12.4 These Terms are governed by the laws of England and Wales, and the courts of England and Wales shall have exclusive jurisdiction over any dispute arising from them.