Service Bulletin



SUBJECT:	Intermittently TV Does Not Turn On with Remote
PRODUCT:	LED TV
BULLETIN NUMBER:	ASC20230124001
CREATE DATE:	01/24/2023 REVISION DATE:
MODELS:	QN85QN95BAFXZA, QN75QN95BAFXZA, QN65QN95BAFXZA, QN55QN95BAFXZA, QN85QN95BDFXZA, QN75QN95BDFXZA, QN65QN95BDFXZA, QN55QN95BDFXZA

Important: Service bulletins are published for informational purposes only and are intended for use only by personnel qualified for the specific tasks depicted. The information contained in this service bulletin does not expand or otherwise alter Samsung's standard limited warranty applicable to the product. This information is published for experienced repair technicians only and is not intended for use by the public. It does not contain warnings to advise non-technical individuals of possible dangers in attempting to service a product. Only experienced professional technicians should repair products powered by electricity. Any attempt to service or repair the product or products dealt with in this service bulletin by anyone else could result in serious injury or death. Information provided in this document is subject to change or update without notice.

SYMPTOMS:

The TV does not turn On with remote control intermittently.

REPAIR:

Upgrade the One Connect Sub Micom to version 1426 or higher.

Instructions:

- 1. Upgrade the TV software to the latest version via OTN or from samsung.com (currently 1420.9).
- Download the two .bin files attached to this bulletin (PTMMICOM_OCTV.bin and MICOM_OCJP.bin) and copy them to the root of a USB drive. Insert the USB drive in the One Connect Box.
- 3. Go to factory menu and upgrade the main board Sub Micom to version 1002 and then upgrade the One Connect Box Sub Micom to version 1426 using the bin files on the USB. See upgrade instructions below.
- 4. After both upgrades are done, verify that you have the following versions. You can see these versions in the first page of the factory menu or the About TV screen.

Main Software: 1420.9 or higher Main Board Sub Micom: 1002

One Connect Sub Micom: 1426_D0B



Sub Micom Upgrade Instructions:

- 1. Enter Factory Menu and navigate to Option > SVC > Upgrade > **SUBMICOM UPGRADE** and press select on the remote control.
- 2. Press the Right arrow on the remote control to start the upgrade. TV will reboot when the upgrade is done.
- 3. Now repeat steps 1 & 2 but this time slelect SUBMICOM JP USB UPGRADE



NOTE: Consult the Samsung Service Website at http://gspn3.samsungcsportal.com for the Service Manual and other information on this product.