


BOSS V1.2

POWER FEEDING INSTRUCTIONS

The new BOSS has a typeC USB connector that can be used to feed power.

See below the J25 jumper used to control the powering patterns and instructions.



JUMPER ON:

1> Feed power ONLY to the BOSS >> it will feed the RPI

2> feed power to the ONLY RPI >> it will feed the BOSS

JUMPER OFF:

Feed power to the BOSS and the RPI individually.