

Energy Management System (EMS) Upgrades for Commercial Facilities



Implement an **Energy Management System (EMS)** in your building for advanced control strategies, real-time monitoring, and optimized energy management.

Is An EMS Project Right for You?

- Does your building use a multi-zone air-side system, DX units, or chillers that would benefit from centralized controls?
- Is your building currently managed by an outdated, monitoring-only EMS or pneumatic thermostats with limited or no centralized control?
- Do you lack real-time visibility, trends and alarms to understand how your HVAC systems are operating?
- Are systems running inefficiently due to fixed setpoints, manual schedules, or limited control capabilities?

ComEd has incentives available to help customers implement Energy Management Systems. **Scan the code below** to see how you can save money and energy.



Email **BusinessEE@ComEd.com**

Call **855-433-2700**

Visit **ComEd.com/Standard**

Benefits

You can lower energy costs and consumption by improving the performance of your EMS. An authorized Energy Efficiency Service Provider will assist you in every step of the way to implement advanced strategies that will help your facility optimize its energy use.

Consider these energy-efficiency opportunities:

- **Installing a new EMS** will benefit the building by **providing centralized control, system trending, real time fault detection, data driven decision making, and improved occupant comfort** through more stable temperatures, better air quality, and responsive system control
- **Temperature and pressure reset:** Reduces fan, cooling, and heating energy by avoiding fixed setpoints
- **Lockouts, DCV, Economizer:** Reduces heating and cooling loads by preventing simultaneous heating and cooling, reducing unnecessary outdoor air and using free outside air cooling
- **Chiller lockout, pump control, and cooling tower fan speed control:** Ensures equipment operates only when needed and at the most efficient operating points, eliminating wasteful and unnecessary operation