### **Contents**

- Event Groups
- Task Notifications

HAN Embedded Systems Engineering – MIC5



Barry, R. (2016). Mastering the freertos real time kernel. Pre-release 161204 Edition. Real Time Engineers Ltd. Chapter 8

### Event driven design

Real-time embedded systems have to take actions in response to events

Events must be communicated to tasks, for example with semaphores and queues

Properties of this type of communication are:

- Allows a task to wait in the Blocked state for a single event to occur
- Unblock a single task (the one with the highest priority) when the event occurs

### Event driven design

Event groups are another FreeRTOS feature

Properties of event groups are:

- Allows a task to wait in the Blocked state for a combination of one of more events to occur.
- Unblock all the tasks that were waiting for the same event, or combination of events, when the event occurs

### Event driven design

This makes event groups useful for:

- synchronizing multiple tasks
- broadcasting events
- allowing a task to wait in the Blocked state for any one of a set of events to occur
- allowing a task to wait in the Blocked state for multiple actions to complete
- possibly reduce RAM usage, because they may replace many binary semaphores

## Characteristics of an Event Group

An event 'flag' or 'bit' is a Boolean (1 or 0) stored in a single bit

- 0: event has not occurred
- 1: event has occurred

An event 'group' is a set of event flags: EventBits\_t

An application designer assigns the meaning to individual bits




Figure 71 Event flag to bit number mapping in a variable of type EventBits\_t

# Characteristics of an Event Group

The number of event bits in an event group is dependent on configUSE\_16\_BIT\_TICKS

- If configUSE\_16\_BIT\_TICKS is 1, then each event group contains 8 usable event bits
- If configUSE\_16\_BIT\_TICKS is 0, then each event group contains 24 usable event bits

Event groups are referenced using variables of type EventGroupHandle\_t.

```
EventGroupHandle_t xEventGroupCreate( void );
```

Listing 132. The xEventGroupCreate() API function prototype

If NULL is returned, then the event group cannot be created.

A non-NULL value being returned indicates that the event group has been created successfully. The returned value is the handle to the created event group.

Notify one or more tasks that the events represented by the bit, or bits, being set has occurred.

Listing 133. The xEventGroupSetBits() API function prototype

The handle of the event group in which bits are being set.

Notify one or more tasks that the events represented by the bit, or bits, being set has occurred.

Listing 133. The xEventGroupSetBits() API function prototype

A bit mask that specifies the event bit, or event bits, to set to 1 in the event group. The value of the event group is updated by **bitwise ORing** the event group's existing value with the value passed in uxBitsToSet.

Notify one or more tasks that the events represented by the bit, or bits, being set has occurred.

Listing 133. The xEventGroupSetBits() API function prototype

The value of the event group at the time the call to xEventGroupSetBits() returned.

Read the value of an event group, and optionally wait in the Blocked state for one or more event bits in the event group to become set.

The **unblock condition** is specified by two variables

- uxBitsToWaitFor specifies which event bits in the event group to test
- xWaitForAllBits specifies if a single of those bits must be set (bitwise OR test), or if all those bits must be set (bitwise AND test)

A task will not enter the Blocked state if its unblock condition is met at the time xEventGroupWaitBits() is called.

### Example unblock conditions

Event group value	uxBitsToWaitFor	xWaitForAllBits	Resultant Behavior
0b0000000	0b00000101	pdFALSE	The calling task will enter the Blocked state because neither of bit 0 or bit 2 are set.
0b0000100	0b00000101	pdTRUE	The calling task will enter the Blocked state because bit 0 and bit 2 are not both set
0b0000100	0b0000101	pdFALSE	The calling task will not enter the Blocked state because bit 2 is already set
0b00000111	0b00000101	pdTRUE	The calling task will not enter the Blocked state because both bits are already set

Read the value of an event group, and optionally wait in the Blocked state for one or more event bits in the event group to become set, if the event bits are not already set.

Listing 135. The xEventGroupWaitBits() API function prototype

The handle of the event group in which bits are being set.

Read the value of an event group, and optionally wait in the Blocked state for one or more event bits in the event group to become set, if the event bits are not already set.

Listing 135. The xEventGroupWaitBits() API function prototype

A bit mask that specifies the event bit, or event bits, to test in the event group.

Read the value of an event group, and optionally wait in the Blocked state for one or more event bits in the event group to become set, if the event bits are not already set.

Listing 135. The xEventGroupWaitBits() API function prototype

If xWaitForAllBits is set to **pdFALSE**, then a task will leave the Blocked state when **any** of the bits specified by uxBitsToWaitFor become set.

If xWaitForAllBits is set to **pdTRUE**, then a task will leave the Blocked state when **all** of the bits specified by uxBitsToWaitFor become set.

HAN\_UNIVERSITY

Read the value of an event group, and optionally wait in the Blocked state for one or more event bits in the event group to become set, if the event bits are not already set.

Listing 135. The xEventGroupWaitBits() API function prototype

If the calling task's unblock condition has been met, and xClearOnExit is set to pdTRUE, then the event bits specified by uxBitsToWaitFor will be cleared back to 0 in the event group.

Read the value of an event group, and optionally wait in the Blocked state for one or more event bits in the event group to become set, if the event bits are not already set.

Listing 135. The xEventGroupWaitBits() API function prototype

The maximum amount of time the task should remain in the Blocked state to wait for its unblock condition to be met.

Read the value of an event group, and optionally wait in the Blocked state for one or more event bits in the event group to become set, if the event bits are not already set.

Listing 135. The xEventGroupWaitBits() API function prototype

The value of the event group at the time the calling task's unblock condition was met or the value at the time the block time expired.

```
int main(void)
    rgb init();
   xSerialPortInit(921600, 128);
    vSerialPutString("\r\nFRDM-KL25Z FreeRTOS demo Week 6 - Example 01\r\n");
   vSerialPutString("By Hugo Arends\r\n\r\n");
                            "vTask1",
                                             configMINIMAL STACK SIZE, (void *)1, 3, NULL );
   xTaskCreate(vTask,
                            "vTask2",
"vTask3",
                                             configMINIMAL STACK SIZE, (void *)2, 2, NULL );
   xTaskCreate(vTask,
   xTaskCreate(vTask,
                                             configMINIMAL STACK SIZE, (void *)3, 1, NULL );
   xTaskCreate(vEventReader, "vEventReader", configMINIMAL STACK SIZE, NULL,
                                                                                  4. NULL ):
   // Create the event group
   xEventGroup = xEventGroupCreate();
    /* Start the scheduler so the tasks start executing. */
   vTaskStartScheduler();
    /* If all is well then main() will never reach here as the scheduler will
    now be running the tasks. If main() does reach here then it is likely that
   there was insufficient heap memory available for the idle task to be created.
    Chapter 2 provides more information on heap memory management. */
   for(;;);
}
```

```
static void vTask(void *parameters)
   char str[48];
   // Set task specific values.
   int32 t n = (int32 t)parameters;
   TickType t xLastWakeTime = xTaskGetTickCount();
   TickType t xDelayMs = xDelaysMs[n-1];
   sprintf(str, "[% 7d - Task %d
                                     Created\r\n", xLastWakeTime, n);
   vSerialPutString(str);
   // As per most tasks, this task is implemented in an infinite loop.
   for(;;)
       // Wait
       vTaskDelayUntil(&xLastWakeTime, xDelayMs);
       // Print info
       sprintf(str, "[% 7d - Task %d ] Set bit %d\r\n", xLastWakeTime, n, (n-1));
       vSerialPutString(str);
       // Set the bit in the event group
       xEventGroupSetBits(xEventGroup, xEventBits[n-1]);
```

```
static void vEventReader(void *parameters)
{
    char str[48];
    EventBits_t xEventGroupValue;
    const EventBits_t xBitsToWaitFor = xEventBits[0] | xEventBits[1] | xEventBits[2];
    const BaseType_t xWaitForAllBits = pdTRUE; // pdFALSE

    sprintf(str, "[% 7d - EventReader] Created\r\n", xTaskGetTickCount());
    vSerialPutString(str);
```

```
// As per most tasks, this task is implemented in an infinite loop.
for(;;)
    // Block to wait for event bits to become set within the event group.
    xEventGroupValue = xEventGroupWaitBits(xEventGroup,
                                           xBitsToWaitFor,
                                           pdTRUE,
                                           xWaitForAllBits,
                                           portMAX DELAY);
    // Prepare the string
    sprintf(str, "[% 7d - EventReader] EventBits: 000..0", xTaskGetTickCount());
    // Add the value of the last three bits
    strcat(str, ((xEventGroupValue & xEventBits[2]) != 0) ? "1" : "0");
    strcat(str, ((xEventGroupValue & xEventBits[1]) != 0) ? "1" : "0");
    strcat(str, ((xEventGroupValue & xEventBits[0]) != 0) ? "1" : "0");
    // Finalize string and print it
    strcat(str, "\r\n");
    vSerialPutString(str);
```

#### xWaitForAllBits = pdFALSE;

```
0 - EventReader] Created
    1 - Task 1
                   1 Created
    2 - Task 2
                    1 Created
    3 - Task 3
                    1 Created
 1001 - Task 1
                   1 Set bit 0
 1002 - EventReaderl EventBits: 000..0001
 2001 - Task 1
                    1 Set bit 0
 2002 - EventReader] EventBits: 000..0001
 3001 - Task 1
                   1 Set bit 0
 3002 - EventReaderl EventBits: 000..0001
                     Set bit 0
 4001 - Task 1
 4002 - EventReader] EventBits: 000..0001
 5001 - Task 1
                    1 Set bit 0
 5002 - EventReader] EventBits: 000..0001
 5002 - Task 2
                    1 Set bit 1
 5004 - EventReader] EventBits: 000..0010
 6001 - Task 1
                   1 Set bit 0
 6002 - EventReader] EventBits: 000..0001
 7001 - Task 1
                   1 Set bit 0
 7002 - EventReader] EventBits: 000..0001
 8001 - Task 1
                    1 Set bit 0
 8002 - EventReader] EventBits: 000..0001
 9001 - Task 1
                    1 Set bit 0
 9002 - EventReader] EventBits: 000..0001
10001 - Task 1
                    ] Set bit 0
10002 - EventReader] EventBits: 000..0001
10002 - Task 2
                   1 Set bit 1
10004 - EventReader] EventBits: 000..0010
10003 - Task 3
                   1 Set bit 2
10006 - EventReader] EventBits: 000..0100
11001 - Task 1
                   1 Set bit 0
11002 - EventReader | EventBits: 000..0001
```


#### xWaitForAllBits = pdTRUE;

```
0 - EventReader] Created
    1 - Task 1
                      Created
    2 - Task 2
                      Created
    3 - Task 3
                     Created
 1001 - Task 1
                      Set bit 0
 2001 - Task 1
                      Set bit 0
 3001 - Task 1
                      Set bit 0
 4001 - Task 1
                      Set bit 0
 5001 - Task 1
                      Set bit 0
 5002 - Task 2
                      Set bit 1
 6001 - Task 1
                      Set bit 0
 7001 - Task 1
                      Set bit 0
 8001 - Task 1
                      Set bit 0
 9001 - Task 1
                      Set bit 0
10001 - Task 1
                      Set bit 0
10002 - Task 2
                      Set bit 1
10003 - Task 3
                      Set bit 2
10004 - EventReader
                      EventBits: 000..0111
11001 - Task 1
                      Set bit 0
12001 - Task 1
                    ] Set bit 0
```

# Task Synchronization Using an Event Group

Goal: to synchronize three tasks with event groups

Problem example: the bits in the event group are already cleared!



# Task Synchronization Using an Event Group

xEventGroupSync() is a special function for task synchronisation with event groups

- It allows a task to set one or more event bits in an event group
- It then waits for a combination of event bits to become set in the same event group as a single uninterruptable operation.

Listing 142. The xEventGroupSync() API function prototype

### Summary

- Practical uses for event groups.
- The advantages and disadvantages of event groups relative to other FreeRTOS features.
- How to set bits in an event group.
- How to wait in the Blocked state for bits to become set in an event group.
- How to use an event group to synchronize a set of tasks.

HAN Embedded Systems Engineering – MIC5



Barry, R. (2016). Mastering the freertos real time kernel. Pre-release 161204 Edition. Real Time Engineers Ltd. Chapter 9

### FreeRTOS communication

### Set of independent tasks that:

- Communicate with each other
- Collectively implement system functionality

### So far we have used communication objects

```
void vTask1( void *pvParam )
                                                         void vTask2( void *pvParam )
 for(;;)
                                                           for(;;)
                                   The communication
    /* Write function code
                                                             /* Write function code
                                   object could be a
   here. */
                                                             here. */
                                   queue, event group,
                                   or one of the many
                                   types of semaphore
    /* At some point vTask1
                                                             /* At some point vTask2
    sends an event to
                                                             receives an event from
   vTask2. The event is
                                                             vTask1. The event is
   not sent directly to
                                                             not received directly
   vTask2, but instead to
                                                             from vTask1, but instead
   a communication object.
                                                             from the communication
                                                             object. */
                                     Communication
    ASendFunction();
                                                           AReceiveFunction();
                                         object
```

### FreeRTOS communication

We can use task notifications instead, to send an event directly

Enabled by setting configUSE\_TASK\_NOTIFICATIONS to 1

```
void vTask1( void *pvParam )
                                                         void vTask2( void *pvParam )
  for(;;)
                                                           for(;;)
    /* Write function code
                                                             /* Write function code
    here. */
                                                             here. */
                                   This time there is no
                                   communication
                                   object in the middle
                                                             /* At some point vTask2
    /* At some point vTask1
    sends an event to
                                                             receives a direct
    vTask2 using a direct to
                                                             notification from vTask1
    task notification.*/
    ASendFunction();-
                                                            AReceiveFunction();
}
```

Figure 77 A task notification used to send an event directly from one task to another

### Task notification characteristics

#### Each task has a **Notification State**:

- Pending
   When a task receives a notification, its notification state is set to pending.
- Not-Pending
   When a task reads its notification value, its notification state is set to not-pending.

#### Each task has a **Notification Value**:

A 32-bit unsigned integer

A task can wait in the Blocked state, with an optional time out, for its notification state to become pending.

### **Benefits**

When compared to a queue, semaphore or event group to perform an equivalent operation

- Performance significantly faster
- RAM usage significantly less RAM

### Limitations

Scenarios in which a task notification cannot be used

- Sending an event or data to an ISR
- Buffering multiple data items
- Broadcasting to more than one task
- Waiting in the blocked state for a send to complete

If a task attempts to send a task notification to a task that already has a notification pending, then it is not possible for the sending task to wait in the Blocked state for the receiving task to reset its notification state.

## **Using Task Notifications**

#### **API** functions overview

<u>Lightest weight</u> and <u>fastest alternative</u> to a binary or counting semaphore

<u>Lighter weight</u> and <u>faster alternative</u> to a binary or counting semaphore, or event group, or queue of length one

# Sending

#### xTaskNotifyGive(...) xTaskNotifyGiveFromISR(...)

- Sets notification state to pending
- Notification value: +1

#### ulTaskNotifyTake(...)

Receiving

- Task optionally waits in Blocked state for notification state to become pending
- Notification value: -1 or cleared to 0

# xTaskNotify(...) xTaskNotifyFromISR(...)


- Sets notification state to pending
- Notification value: +1 or set bits or a completely new number

#### xTaskNotifyWait(...)

- Task optionally waits in Blocked state for notification state to become pending
- Notification value: bits to clear on entry and bits to clear on exit

# Task Notifications Example

See Week 6 – Example 03



### Summary

- A task's notification state and notification value.
- How and when a task notification can be used in place of a communication object, such as a semaphore.
- The advantages of using a task notification in place of a communication object.