




	Power	Joystick	Userport	Audio/Video	Serial	Tape
C(1)16 Plus/4	 center negative	 JOYSTICK 1 JOYSTICK 2 1. JOYX1 JOYB1 Up 2. JOYX1 JOYB1 Down 3. JOYX2 JOYB2 Left 4. JOYX2 JOYB2 Right 5. +5VDC +5VDC +5V 6. BUTTON A BUTTON B Fire Button 7. GROUND GROUND Ground 8. DATA 2 DATA 1 Select		 1. Luminance (S-video Y signal) 2. Ground 3. Audio out 4. Composite video 5. Audio in 6. Chrominance (S-video C signal) 7. Not Connected 8. +5 Volt 8 pin DIN (262") audio video connector	 1. SRQ 2. Ground 3. ATN (Attention) 4. Clock 5. Data 6. Reset 6 pin DIN IEC serial connector	 1. Ground 2. +5 Volt 3. Motor 4. Read 5. Write 6. Sense 7. Ground
	 1. Ground (5 Volt) 2. Ground (5 Volt) 3. Ground (5 Volt) 4. 5 Volt DC or NC; 5. 5 Volt DC 6. 9 Volt AC 7. 9 Volt AC  1. +5 Volt DC 2. Ground 3. 9 Volt AC 4. 9 Volt AC	 JOYSTICK 1 JOYSTICK 2 1. JOYX1 JOYB1 Up 2. JOYX1 JOYB1 Down 3. JOYX2 JOYB2 Left 4. JOYX2 JOYB2 Right 5. +5VDC +5VDC +5V 6. BUTTON A BUTTON B Fire Button 7. GROUND GROUND Ground 8. DATA 2 DATA 1 Select	1 2 3 4 5 6 7 8 9 10 11 12 A B C D E F H J K L M N 1. Ground 2. +5 Volt 3. Reset 4. P2 5. P3 6. P4 7. P5 8. Receive Clock 9. SERIAL ATN 10. 9 Volt AC 100 mA 11. 9 Volt AC 100 mA 12. Ground A. Ground B. P0 C. RX D. RTS E. DTR F. PB7 H. DCID J. P6 K. P1 L. CSR M. TX N. Ground	 1. Luminance (S-video Y signal) 2. Ground 3. Audio out 4. Composite video 5. Audio in 6. Chrominance (S-video C signal) 7. Not Connected 8. +5 Volt 8 pin DIN (262") audio video connector	 1. SRQ 2. Ground 3. ATN (Attention) 4. Clock 5. Data 6. Reset 6 pin DIN IEC serial connector	 1. Ground 2. +5 Volt 3. Motor 4. Read 5. Write 6. Sense 7. Ground

C16



[PIN]	K0 [18]	K1 [15]	K2 [14]	K7 [3]	K4 [7]	K5 [9]	K6 [10]	K3 [17]
P7 [6]	1	CLR	CTRL	Run Stop	Space	Q	2	
P0 [8]	3	W	A	Shift	Z	S	E	4
P2 [12]	5	R	D	X	C	F	T	6
P1 [11]	7	Y	G	V	B	H	U	8
P3 [13]	9	I	J	N	M	K	O	0
P6 [1]	▼	P	L	.	.	:	-	▲
P4 [16]	*	;	/	ESC	=	+		▶
P5 [19]	Del	Return	£	@	F1	F2	F3	Help

pin [2] KEY (NC)
pin [5],[20] NC
pin [4] + 5 Volt

Keyboards

<https://mydoomportal V1.0>

Expansion

25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
CC	BB	AA	Z	Y	X	W	V	U	T	S	R	P	N	M	L	K	J	H	F	E	D	C	B	A
1. Ground	2. +5 Volt	3. +5 Volt	4. IRQ	5. R/W	6. C1 High	7. C2 Low	8. C2 High	9. CS1 (SC000-SFFFF)	10. CS0 (S8000-SBFFF)	11. CAS	12. Mux	13. BA	14. D7	15. D6	16. D5	17. D4	18. D3	19. D2	20. D1	21. D0	22. AEC	23. Audio In	24. φ2	25. Ground
A. Ground	B. C1 Low	C. Reset	D. RAS	E. φ0	F. A15	H. A14	J. A13	K. A12	L. A11	M. A10	N. A9	P. A8	R. A7	S. A6	T. A5	U. A4	V. A3	W. A2	X. A1	Y. A0	Z. N.C.	AA. N.C.	BB. N.C.	CC. Ground