# Xilinx Zynq FPGA, TI DSP, MCU 기반의 프로그래밍 및 회로 설계 전문가 과정

강사 - Innova Lee(이상훈) gcccompil3r@gmail.com 학생 - 장성환 redmk1025@gmail.com

```
73 static const hetINSTRUCTION_t het1PROGRAM[58U] =
74 {
75
       /* CNT: Timebase
                                               = 0
76
               - Instruction
                                               = 1
77
               - Next instruction
               - Conditional next instruction = na
78
79
               - Interrupt
80
               - Pin
                                                = na
81
               - Reg
                                               = T
82
83
           /* Program */
84
          0x00002C80U,
85
          /* Control */
          0x01FFFFFFU,
87
88
           /* Data */
89
          0xFFFFFF80U,
          /* Reserved */
90
91
          0x00000000U
      },
```

CNT 명령어를 살펴보자.

Instruction Set www.ti.com

#### 23.6.3.8 CNT (Count)

```
Syntax

CNT {

[brk={OFF | ON}]

[next={label | 9-bit unsigned integer}]

[reqnum={3-bit unsigned integer}]

[request={NOREQ | GENREQ | QUIET}]

[angle_count={OFF | ON}]

[reg={A | B | T | NONE}]

[comp ={EQ | GE}]

[irq={OFF | ON}]

[control={OFF | ON}]

max={25-bit unsigned integer}

[data={25-bit unsigned integer]
}
```

#### Figure 23-134. CNT Program Field (P31:P0)



#### Figure 23-135. CNT Control Field (C31:C0)



### Figure 23-136. CNT Data Field (D31:D0)

31	7 6	0
Data		Reserved
25		7

처음 Program Field에 채워지는 값은 0x00002C80

따라서, 13, 11, 10, 7 비트 ON,

Next program address - 1

Instruction – 6 (CNT)

Register - 2 (T)

reqnum\* Defines the number of the request line (0,1,..,7) to trigger either the HTU or the DMA.

Default: 0

Location: Program field [25:23]

BRK Defines the software breakpoint for the device software debugger.

Default: OFF

Location: Program field [22]

next Defines the program address of the next instruction in the program flow. This value

may be a label or an 9-bit unsigned integer.

Default: Current instruction + 1 Location: Program field [21:13]

Pin\* Pin Select: Selects the pin on which the action occurs. Enter the pin number.

Default: pin 0

Location: Control field [12:8] except PCNT

request\* Allows to select between no request (NOREQ), request (GENREQ) and quiet request

(QUIET). See Section 23.2.9.

Default: No request

Location: Control Field [28:27]

Request	C[28]	C[27]	To HTU	To DMA
NOREQ	0	0	no request	
NOREQ	1	0	no request	no request
GENREQ	0	1	request	request
QUIET	1	1	quiet request	no request

## 컨트롤 비트 0x01FFFFFFU

[24:0] 을 ON한다. MAXCNT의 수가 3355431만큼 가능하다.

데이터 비트 OxFFFFFF80

[31:7]를 ON 한다.

모든 데이터가 1로 채워지며 10진수로 4294967168이 된다.